

$$q_v = k \times \sqrt{\Delta P_m}$$

## NOP/NOT/NOP-S/NOT-S

NOP/NOT/NOP-S/NOT-S		k				
		125	160	200	250	315
Säätöasento Injusteringsläge Adjustment settings	4,5-5	20	33	49	90	167
	4	18	29	42	76,5	137
	3,5	15	24	33	59,5	110
	3	13	20	27	47,3	88
	2,5	10,5	16	21	38	71
	2	9	13,2	17,2	31,4	55
	1,5	7,5	10,4	13,9	26	44
	1	6	8,4	10,6	21,3	35
	0,5	5	6,5	8,2	16,8	27
	0	4	4,9	5,6	14	21

Säätösuunta • Adjustment direction • Rotationsriktningen

