




Venttiili


VTTB





Venttiili

VTTB



Ø mm	Venttiili Asennus- paikka	Asento a [mm]								
		a	4	5	6	7	8	10	12	16
100	Kanava	k	0,919	0,967	1,17	1,45	1,58	1,89	2,00	3,24
		a	4	5	6	7	8	10	12	16
125	Kanava	k	1,11	1,47	1,69	2,01	2,21	2,72	3,46	4,54
		a	5	8	10	12	16	20		
160	Kanava	k	2,05	2,93	3,51	3,92	5,19	7,20		
		a								