



[illegible]

KQ1L-A

安装方法 Installation method




二合一
two-in-one




塑料螺母
Plastic Nut


阀门开关(下压为开)
Valve switch (press down to open)



主轨 Main track





三节滚珠导轨
Three-section rail




(A)*4

(B)*4




(H)*6

(I)*1





(I) 副轨
(I) Sub rail




(F)*4

(G)*4



(C)*4


(D)*4




KQ1L-A

安装方法

Installation method




二合一
two-in-one




塑料螺母
Plastic Nut


阀门开关(下压为开)
Valve switch (press down to open)



主轨 Main track





三节滚珠导轨
Three-section rail



(C)*4



(D)*4

(E)*4





(I)*1

(H)*6



(C)*4


(D)*4



(M)*2

(N)*1


(O)*4




安装方法


Installation method


(K)*8



9

(J)*1

(L)*1



11

