













LINSY 林氏家居		五金表/Hardware list				部件表/Parts List				
安装示意图/Assembly Instruction		 (A)*13 小二合一杆 2-in-1 small rod	 (B)*13 小三合一锁饼 3-in-1 small lock	 (C)* 17 二合一螺杆 (35mm) 2-in-1-screw	 (D)* 17 大三合一锁饼 (15mm) Three-in-one large lock	编号NO.	名称Name	规格(mm) Specification	数量QTY	材质Material
产品名称 Model NO.	NU1M-B	 (E)* 17 木榫Ø8x30mm wood tenon	 (F)*13 塑料螺母 Plastic Nut	 (G)* 13 自攻螺丝M4x40mm Self tapping screw	 (H)* 44 自攻螺丝M3.5x12mm Self tapping screw	①	侧板Side board	346*270*125	2	三胺板 Melamine
产品规格 Specification	2600~2120*350*349mm					②	面板Top panel	1546*346*15	1	三胺板 Melamine
安装工具 Tool	安装人数Installer					③	底板Bottom board	1546*346*15	1	三胺板 Melamine
 						④	中侧板Middle side board	298*240*15	2	三胺板 Melamine
						⑤	前脚条Front foot strip	1680*58*25	1	三胺板 Melamine
		⑥	侧脚条Side foot strip	258*58*25	4	三胺板 Melamine				
		⑦	背板Back board	1556*250*5	1	三胺板 Melamine				
		⑧	右抽屉面板Drawer's panel (R)	548*236*15	1	三胺板 Melamine				
		⑨	左抽屉面板Drawer's panel (L)	548*236*15	1	三胺板 Melamine				
		⑩	中抽屉面板Drawer's middle board	582*236*15	1	三胺板 Melamine				
		⑪	抽屉左侧板Drawer's side board (L)	295*142*12	3	三胺板 Melamine				
		⑫	抽屉右侧板Drawer's side board (R)	295*142*12	3	三胺板 Melamine				
		⑬	边抽屉后板Side drawer back plate	432*142*12	2	三胺板 Melamine				
		⑭	中抽屉后板Middle drawer rear plate	502*142*12	1	三胺板 Melamine				
		⑮	边抽屉底板Side drawer base plate	442*291*5	2	三胺板 Melamine				
		⑯	中抽屉底板Middle drawer bottom plate	512*291*5	1	三胺板 Melamine				
		⑰	附柜面板Attached counter board	1210*350*25	1	木皮板Wood veneer				
		⑱	饰板Trim panel	250*250*20	1	三胺板 Melamine				
		⑲	立柱Column	250*250*304	1	实木 Wood				
		⑳	岩板rock beam	1800*350*6	1	岩板rock beam				

NU1M-B

安装方法
Installation method




二合一
two-in-one




塑料螺母
Plastic Nut


阀门开关(下压为开)
Valve switch (press down to open)



主轨 Main track




三节滚珠导轨-10"
Three-section rail




(A)*8




(B)*8






X2



(F)*12





(G)*12



(A)*4




(B)*4



(H)*18




(I)*3




(I)副轨
(I)Sub rail

NU1M-B





安装方法
Installation method





二合一
two-in-one



反弹器安装及调节方法
Installation and adjustment
method of Bouncer





5





6

7



8

安装方法 Installation method



反弹器安装及调节方法

Installation and adjustment method of Bouncer

