




部件表/Parts List


$$1/4$$



TV2E-A

安装方法


Installation method

二合一
two-in-one阀门开关(下压为开)
Valve switch (press down to open)


前 Forward 后 Back

三节滚珠导轨-10"
Three-section rail


塑料螺母 Plastic Nut



(C)*24




(D)*24




× 6


1



(K)*24




(G)*24




× 6


2



(E)*36




(H)*6


(H) 副轨
(H) Sub rail

× 6


3




(A)*1




(B)*5



(M)*6



(O)*2










4

TV2E-A



安装方法

Installation method

阀门开关(下压为开)
Valve switch (press down to open)



安装方法
Installation method



背板扣
Back Plate Buckle

