


Bailey BL-CTG5801 Assembly Manual




A=4

B=4

C=4

D=1

