ASSEMBLY INSTRUCTION



IMPORTANT PLEASE READ BEFORE YOU CONTINUE

The product you've purchased will give you many years of reliable use when assembled and cared for properly. Please follow these guidelines for safe assembly, maintenance, and cleaning.

DO NOT use power tools to assemble this product.

Using power tools may cause damage, make the product unsafe, and will void any warranty or claim.

Maintenance:


Over time, and depending on how often the product is used, some fittings may loosen slightly. This is completely normal for flat-pack furniture. Simply check and **tighten any fixings** from time to time to keep everything secure.

Cleaning & Care:

- Wipe with a **damp (not wet)** cloth.
- Use a dry duster or standard furniture polish for regular cleaning.


Avoid using abrasive or chemical cleaners.

WARNING: Use of power tools to assemble this product will invalidate any warranty or claim and may damage the product, making it unsafe.



HARDWARE LIST

LABEL	PICTURE	DESCRIPTION	QTY
А	(b)	M8*20 BOLT	12PCS
В	(mm) (e)	M8*40 BOLT	4PCS
D		NUT	4 PCS
E	0	M8 WASHER	12PCS
F		SOCKET SPANNER	1 PC
G		ALLEN KEY	1 PC
Н	\Diamond		24PCS
I			12PCS






A 60 8PCS M8*20 BOLT

E © 8 PCS

M8 WASHER

G 1 PC
ALLEN KEY



STEP 4

A **6** 4 PCS M8*20 BOLT

B 6 4 PCS

M8*40 BOLT

D 🖨 4 PCS NUT

E @ 4 PCS M8 WASHER

G 1 PC
ALLEN KEY

F 1 PC SOCKET SPANNER

