



充电式手电钻 或者 十字螺丝刀
Cordless hand drill
Phillips screwdriver



安装人数Installer



内六角螺丝垫片安装顺序
Installation sequence of hexagon socket screw gasket

安装示意图/Assembly Instruction

产品名称 Model NO. LH586P1-A/C

产品规格 Specification 0.6m置物架


尺寸组合 Combined size 560*540*1840mm

配件表/Accessories list

部件表/Parts List

编号 NO.	名称Name	图示Icon	数量QTY	编号 NO.	名称Name	规格 Specification	数量 QTY	材质material
A	M6*30内六角螺栓 M6*30 Hexagon socket bolt		18	①	侧板 Side board	1610*510*20	1	红橡木+铁+铜+塑料 Red oak+Iron+Copper+Plastic
B	M6*10弹垫 shim-(M6*10mm) spring		18	②	立板 Standing board	1840*540*20	1	红橡木+铁+铜+塑料 Red oak+Iron+Copper+Plastic
C	M6*13平垫 shim-(M6*13mm) colored zinc		18	③	置物板1 Panel 1	480*500*20	1	红橡木 Red oak
D	4mm内六角扳手 spanner-(4mm) hex		1	④	置物板2 Panel 2	500*270*20	1	红橡木 Red oak
E	膨胀管 Expansion tube		2	⑤	置物板3 Panel 3	500*270*20	1	红橡木 Red oak
F	白攻螺丝4*50 Self-tapping screw-(M4*50mm)		2	⑥	中腿 Middle foot	107*40*40	1	红橡木 Red oak
G	挂杆 Hanging rod		2	⑦	置物板4 Panel 4	480*500*20	1	红橡木 Red oak
H	黄色自攻螺丝4*16 Yellow self-tapping screw-(M4*16mm)		8					
I	飞机膨胀塞 Aircraft expansion plug		2					


STEP 1



△ 使用五金A、B、C将部件1与部件2连接。


Connect part 1 to part 2 using hardware A, B and C.

STEP 2




△ 将部件6顺时针旋转连接在部件7上；使用五金A、B、C将部件3、部件4、部件7、部件5与安装好的STEP1连接。

Connect component 6 clockwise to component 7; Connect Parts 3, 4, 7 and 5 to the installed STEP1 using hardware A, B, and C.




STEP 3



△ 根据产品放置位置，将组好的step2用五金E、F固定在实体墙上或用五金I、F固定在空心墙上。

According to the placement of the product, Fix the assembled step2 to the physical wall with hardware E and F or to the hollow wall with hardware I and F.

STEP 4



△ 使用五金H将五金G挂杆固定在部件4的相应位置上。

Use hardware H to fix the hardware G hanging rod to the corresponding position of part 4.