



LINSY 林氏家居


五金表/Hardware list

部件表/Parts List

安装示意图/Assembly Instruction

产品名称 Model NO.	2.0米伸缩电视柜主体
产品型号 Product Model	UD4M-A
尺寸规格 Specification	(1974*398*371)mm
安装工具 Tool	安装人数 Installer
	

注：为保证设计效果，部分尺寸为定制尺寸，不影响使用。




(A)*61 二合一螺杆 2-in-1-screw	(B)*61 大三合一锁销 Three-in-one large lock	(C)*17 木榫Ø8x30mm wood tenon	(D)*44 自攻螺丝M3.5x14mm Self-tapping screw
(E)*11 自攻螺丝M4x30mm Self-tapping screw	(F)*8 背板扣 Back Plate Buckle-White	(G)*2 白色透气孔盖 Breathable cover	(H)*10 脚垫-灰色 Footrest - grey
(I)*2 缓冲门较大号-Ø35 Hinge-big bends	(J)*2 气动杆 Pneumatic rod	(K)*2 三节滚珠导轨-10" three-section ball rail	(L)*55 孔贴(奶白色) PVC Hole stickers
(M)*6 孔贴(木纹色) PVC Hole stickers			

编号NO.	名称Name	规格 (mm) Specification	数量 QTY	材质Material
①	转角木Corner connection wood	398*30*30	4	橡胶木 Rubber wood
②	顶板Top board	1920*397*15	1	刨花板Particle Board
③	底板Bottom board	1920*397*15	1	刨花板Particle Board
④	上拉条Top brace	1944*58*15	1	刨花板Particle Board
⑤	左侧板Side board(L)	289*397*15	1	刨花板Particle Board
⑥	右侧板Side board(R)	289*397*15	1	刨花板Particle Board
⑦	左中侧板Middle side board(L)	313*380*15	1	刨花板Particle Board
⑧	右中侧板Middle side board(R)	313*380*15	1	刨花板Particle Board
⑨	背拉条Back brace	638*58*15	1	刨花板Particle Board
⑩	背板Back board	648*323*5	2	纤维板Fiberboard
⑪	前脚条Front foot strip	1880*58*25	1	刨花板Particle Board
⑫	侧脚条Side foot strip	290*58*25	3	刨花板Particle Board
⑬	下翻门Down swing door	645*286*15	1	刨花板Particle Board
⑭	左抽屉面板Drawer's top panel(L)	645*286*15	1	刨花板Particle Board
⑮	右抽屉面板Drawer's top panel(R)	645*286*15	1	刨花板Particle Board
⑯	抽屉侧板Drawer's sideboard	290*174*15	4	刨花板Particle Board
⑰	抽屉后板Drawer's Back board	612*174*15	2	刨花板Particle Board
⑱	抽屉底托条Drawer's bottom bracket	290*58*15	2	刨花板Particle Board
⑲	抽屉底板Drawer's Bottom board	592*300*5	2	纤维板Fiberboard

►注：门和抽屉都是设计所需设计缝，小心夹伤！
►Note: The doors and drawers are designed with necessary seams. Be careful not to pinch!

UD4M-A
2.0米伸缩电视柜主体

产品分解图/Exploded drawing




部件表/Parts List

①	转角木Corner connection wood
②	顶板Top board
③	底板Bottom board
④	上拉条Top brace
⑤	左侧板Side board(L)
⑥	右侧板Side board(R)
⑦	左中侧板Middle side board(L)
⑧	右中侧板Middle side board(R)
⑨	背拉条Back brace
⑩	背板Back board
⑪	前脚条Front foot strip
⑫	侧脚条Side foot strip
⑬	下翻门Down swing door
⑭	左抽屉面板Drawer's top panel (L)
⑮	右抽屉面板Drawer's top panel (R)
⑯	抽屉侧板Drawer's sideboard
⑰	抽屉后板Drawer's Back board
⑱	抽屉底托条Drawer's bottom bracket
⑲	抽屉底板Drawer's Bottom board

UD4M-A 2米伸缩电视柜主体


安装方法
Installation method

1
阀门开关(下压为开)
Valve switch
(press down to open)




注: 先将A与B拆下来
Note: remove a and B first





2
侧板
side board
后after



3
抽屉侧板
sideboard
of the drawer
后after




4
5
注: 将B对准A后推进去
Note: align B with a
and push it in




UD4M-A 2米伸缩电视柜主体

安装方法
Installation method




大二合一
two-in-one


- (A)*2
- (B)*2




- (A)*6
- (B)*6



- (A)*6
- (B)*6
- (C)*4




- (A)*12
- (B)*12
- (C)*4
- (G)*2



UD4M-A 2米伸缩电视柜主体


安装方法
Installation method

1
阀门开关(下压为开)
Valve switch
(press down to open)




注: 先将A与B拆下来
Note: remove a and B first

2
侧板
side board







3
抽屉侧板
sideboard
of the drawer



4
5
注: 将B对准A后推进去
Note: align B with a
and push it in



三节滚珠导轨
three-section ball rail



UD4M-A 2米伸缩电视柜主体

安装方法
Installation method

大弯big bend

中弯middle bending

直弯straight bending

侧板 side board


门板 door panel

调节上下 Adjust up and down

调节左右 Adjust left and right


调节前后 Before and after adjustment

门铰 Hinge



13

14



(L)*52 (M)*6

孔位贴使用小贴士
产品安装完成后请贴上孔贴，多出的孔贴请保管好

Tips for using hole stickers:
After the product installation is completed, please attach the hole stickers. Please keep any extra hole stickers safe

1、擦干净孔位
1, Clean the hole position thoroughly

2、贴上孔贴
2, Attach hole stickers

3、24小时内勿碰水
3, Do not touch water within 24 hours

15



16

LINSY 林氏家居


五金表/Hardware list

部件表/Parts List

安装示意图/Assembly Instruction

产品名称 Model NO.	1.5米伸缩电视柜附柜
产品型号 Product Model	UD4M-A
尺寸规格 Specification	(1000*398*399)mm
安装工具 Tool	安装人数 Installer
	

注：为保证设计效果，部分尺寸为定制尺寸，不影响使用。




 (A)* 25 二合一螺杆 2-in-1-screw	 (B)* 25 大三合一锁饼 Three-in-one large lock	 (C)* 4 木榫Ø8x30mm wood tenon	 (D)* 2 镜钉 Mirror nail
 (E)* 2 透明塑料垫片 Plastic gasket	 (F)* 2 自攻螺丝M3.5x16mm Self-tapping screw	 (G)* 4 灰色毛毡脚垫 Footrest - Grey	 (H)* 2 垫片-黑色L=600mm rubber pad - Black
 (I)* 25 孔贴 PVC Hole stickers	 (J)* 1 亚克力 Acrylic		

编号NO.	名称Name	规格 (mm) Specification	数量 QTY	材质Material
①	附柜面板Attached counter board	1000*398*25	1	刨花板Particle Board
②	附柜左侧板Sideboard of attached cabinet (L)	371*120*20	1	榉木Beech wood
③	附柜右侧板Sideboard of attached cabinet (R)	371*120*20	1	榉木Beech wood
④	附柜背板Attached back board	371*354*15	1	刨花板Particle Board
⑤	附柜底板Attached bottom board	354*103*15	1	刨花板Particle Board
⑥	附柜层板Shelf of attached cabinet	354*95*15	1	刨花板Particle Board
⑦	前脚条Front foot strip	354*58*15	1	刨花板Particle Board

UD4M-A
1.5米伸缩电视柜附柜

产品分解图/Exploded drawing


部件表/Parts List



①	附柜面板Attached counter board
②	附柜左侧板Sideboard of attached cabinet(L)
③	附柜右侧板Sideboard of attached cabinet(R)
④	附柜背板Attached back board
⑤	附柜底板Attached bottom board
⑥	附柜层板Shelf of attached cabinet
⑦	前脚条Front foot strip


UD4M-A 1.5米伸缩电视柜附柜

安装方法
Installation method




大二合一
two-in-one


- (A)*2
- (B)*2




- 1 (A)*4
- (B)*4



- (A)*12
- (B)*12
- (C)*2



- 3 (D)*2
- (E)*2
- (F)*2
- (J)*1




2

4


UD4M-A 1.5米伸缩电视柜附柜

安装方法
Installation method




大二合一
two-in-one

- (A)*6
- (B)*6
- (C)*2



- (G)*4
- (H)*2




- (I)*24

孔位贴使用小贴士


产品安装完成后请贴上孔贴，多出的孔贴请保管好

Tips for using hole stickers:


After the product installation is completed, please attach the hole stickers. Please keep any extra hole stickers safe




1、擦干净孔位
1, Clean the hole position thoroughly




2、贴上孔贴
2, Attach hole stickers




3、24小时内勿碰水
3, Do not touch water within 24 hours



组合1:
产品名称: UD4M-A 1.5米伸缩电视柜
产品规格: 1616~2270*398*399mm



组合2:
产品名称: UD4M-A 2.0米伸缩电视柜
产品规格: 2096~2750*398*399mm



组合3:
产品名称: UD4M-A 2.4米伸缩电视柜
产品规格: 2493~3147*398*399mm