
ROCK BOARD®
DIGITAL

DISPLAY SETTING INSTRUCTIONS

For all digital product variants




1 Magnet



Use the Magnet to hover over the marked areas.

2 LED Panel Sensors



Colour change sensor (top).

Number change sensor (bottom).

3 Hover Action



Activate Edit Mode
Hover over A or B sensors until digit flashes.


Change State Cycle
Wave the magnet over sensor A or B.

Save State
Wait until digit flashing stops.

! Your settings are saved to memory and retained between power cycles.


A Setting Colour

Colour Cycle Sequence



B Setting Number

Number Cycle Sequence



Video tutorial

Scan to watch