

LPS IDLER ROLLER ASSEMBLY DIAGRAM

ASSEMBLE ROLLER AND SPACERS ONTO SHAFT AND YOKE IN ORDER SHOWN

TO REMOVE SHAFT AND ROLLER
LOOSEN SET SCREW SEVERAL
TURNS WITH .05" HEX WRENCH

ABXS 145 Shim Washer .02

ABX 326 R4 Perma Lube Bearing

ABXS 142 Roller, Idler



PL 700 © 12/15/2020 StoneAge®, All Rights Reserved

LPS IDLER ROLLER ASSEMBLY DIAGRAM

ASSEMBLE ROLLER AND SPACERS ONTO SHAFT AND YOKE IN ORDER SHOWN

TO REMOVE SHAFT AND ROLLER
LOOSEN SET SCREW SEVERAL
TURNS WITH .05" HEX WRENCH

ABXS 145 Shim Washer .02

ABX 326 R4 Perma Lube Bearing

ABXS 142 Roller, Idler



PL 700 © 12/15/2020 StoneAge®, All Rights Reserved



SCAN HERE FOR
MORE RESOURCE
INFORMATION