



SM Swivel Maintenance Kit Contents

SM 610-P16	SM 600-P16
BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1
FS 004-0 (GREASE ZERK, 1/4-28 x 35/64, STRAIGHT, STEEL) x1	PL 524 (SM-P16/P20 HIGH FLOW SWIVELS MANUAL INSERT 11 x 17) x1
PL 524 (SM-P16/P20 HIGH FLOW SWIVELS MANUAL INSERT 11 x 17) x1	SM 011 (Carbide Seat) x1
SM 006 (SEAL, 62mmOD, DOUBLE LIP W/SPRING, RUBBER COVERED) x1	SM 012-O (ASSY, HP SEAL WITH O-RING, .87OD x .60OAL) x1
SM 007 (SEAL, 70mmOD, SINGLE LIP W/SPRING, RUBBER COVERED) x1	SM 600-P20
SM 008 (O-RING, 3.395OD, 70A, BUNA-N) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1
SM 009 (Bearing, 6307 JEM) x3	SM 111 (CARBIDE, SEAT, SM, 1.05OAL COATED) x1
SM 011 (Carbide Seat) x1	SM 112-O (H.P. Seal, P20 w/O-Ring) x1
SM 012-O (ASSY, HP SEAL WITH O-RING, .87OD x .60OAL) x1	
SM 610-P20	
BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	
FS 004-0 (GREASE ZERK, 1/4-28 x 35/64, STRAIGHT, STEEL) x1	
PL 524 (SM-P16/P20 HIGH FLOW SWIVELS MANUAL INSERT 11 x 17) x1	
SM 008 (O-RING, 3.395OD, 70A, BUNA-N) x1	
SM 106 (Seal, Shaft Small) x1	
SM 107 (Seal, Shaft Large) x1	
SM 109 (BEARING, BALL, DEEP GROOVE, OPEN) x4	
SM 111 (CARBIDE, SEAT, SM, 1.05OAL COATED) x1	
SM 112-O (H.P. Seal, P20 w/O-Ring) x1	