



## WG Classic Maintenance Kit Contents

WG 600-ST1	WG 600-V	WG 610-RT1	WG 610-V
BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	BJ 048-F (VISC FLUID, 6oz, FAST (2,000cst)) x1	BJ 010-D (Seal, Shaft) x2	BJ 010-D (Seal, Shaft) x2
HC 012-TO (H.P. SEAL ASSEMBLY) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	BJ 048-F (VISC FLUID, 6oz, FAST (2,000cst)) x1
MJ 011 (BRASS SEAT) x1	HC 012-TO (H.P. SEAL ASSEMBLY) x1	HC 012-TO (H.P. SEAL ASSEMBLY) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1
	MJ 011 (BRASS SEAT) x1	MJ 011 (BRASS SEAT) x1	HC 012-TO (H.P. SEAL ASSEMBLY) x1
	PL 527 (Warthog CLASSIC (WG) USER MANUAL BOOKLET 5.5 x 8.5) x1	MJ 021-S (Weep Seal) x1	MJ 011 (BRASS SEAT) x1
		PL 527 (Warthog CLASSIC (WG) USER MANUAL BOOKLET 5.5 x 8.5) x1	MJ 021-S (Weep Seal) x1
		WG 007 (BEARING, BALL) x2	PL 527 (Warthog CLASSIC (WG) USER MANUAL BOOKLET 5.5 x 8.5) x1
		WG 008 (O-RING, 2-1/4OD, 70A) x1	WG 007 (BEARING, BALL) x2
		WG 014 (WAVE SPRING) x1	WG 008 (O-RING, 2-1/4OD, 70A) x1
		WGP 032 (Retaining Ring) x1	WG 014 (WAVE SPRING) x1
			WGP 032 (Retaining Ring) x1