



WH Classic Maintenance Kit Contents

WH 600-ST1	WH 600-V	WH 610-RT1	WH 610-V
BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	BJ 048-F (VISC FLUID, 6oz, FAST (2,000cst)) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	BJ 048-F (VISC FLUID, 6oz, FAST (2,000cst)) x1
TJ 011 (BRASS SEAT) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1	PL 529 (Warthog CLASSIC (WH) USER MANUAL BOOKLET 5.5 x 8.5) x1	BJ 062-S (ANTISEIZE, COPPER 1.3, 2g POUCH) x1
WH 012-O (ASSY, HP SEAL WITH ORING, .43OD X .52OAL) x1	PL 529 (Warthog CLASSIC (WH) USER MANUAL BOOKLET 5.5 x 8.5) x1	RJ 008 (O-Ring) x1	PL 529 (Warthog CLASSIC (WH) USER MANUAL BOOKLET 5.5 x 8.5) x1
	TJ 011 (BRASS SEAT) x1	RJ 014 (WAVE SPRING) x1	RJ 008 (O-Ring) x1
	WH 012-O (ASSY, HP SEAL WITH ORING, .43OD X .52OAL) x1	RJ 021-S (WEEP SEAL) x1	RJ 014 (WAVE SPRING) x1
		TJ 007 (BEARING, BALL) x2	RJ 021-S (WEEP SEAL) x1
		TJ 011 (BRASS SEAT) x1	TJ 007 (BEARING, BALL) x2
		WH 010 (SEAL, SHAFT) x2	TJ 011 (BRASS SEAT) x1
		WH 012-O (ASSY, HP SEAL WITH ORING, .43OD X .52OAL) x1	WH 010 (SEAL, SHAFT) x2
			WH 012-O (ASSY, HP SEAL WITH ORING, .43OD X .52OAL) x1