



Warthog X Maintenance Kit Contents

WTA 600-ST1	WTA 600-VS	WTA 610-RT1	WTA 610-VS
RJ 011-K (BRASS SEAT) x1	BC 410.15 (Syringe, 20CC) x1	BC 040 (O-RING 7/16OD 90A HARD, BUNA-N) x1	BC 040 (O-RING 7/16OD 90A HARD, BUNA-N) x1
RJ 012-KTO (ASSY, HP SEAL WITH O-RING, .31OD x .23OAL) x1	BJ 048-F (VISC FLUID, 6oz, FAST (2,000cst)) x1	DB 169 (O-RING, 1-1/2OD, 70A, BUNA-N) x1	BC 410.15 (Syringe, 20CC) x1
	FT 115 (ASSY, TUBE for SYRINGE) x1	FT 026 (ASSY, PORT SCREW W/ O-RING) x1	BJ 048-F (VISC FLUID, 6oz, FAST (2,000cst)) x1
	PL 723 (Warthog X (WTA) User Manual Booklet 5.5 x 8.5) x1	RJ 011-K (BRASS SEAT) x1	DB 169 (O-RING, 1-1/2OD, 70A, BUNA-N) x1
	RJ 011-K (BRASS SEAT) x1	RJ 012-KTO (ASSY, HP SEAL WITH O-RING, .31OD x .23OAL) x1	FT 026 (ASSY, PORT SCREW W/ O-RING) x1
	RJ 012-KTO (ASSY, HP SEAL WITH O-RING, .31OD x .23OAL) x1	WS 022-S (WEEP SEAL) x1	FT 115 (ASSY, TUBE for SYRINGE) x1
		WT 006 (SEAL, 19mmOD, DOUBLE LIP WITH SPRING, 5mm WIDE, NITRILE) x1	PL 723 (Warthog X (WTA) User Manual Booklet 5.5 x 8.5) x1
		WTA 007 (BALL BEARING WITH SEALS) x1	RJ 011-K (BRASS SEAT) x1
		WTA 029 (SEAL, 29mm OD, DOUBLE LIP WITH SPRING, 5mm WIDE, NITRILE) x1	RJ 012-KTO (ASSY, HP SEAL WITH O-RING, .31OD x .23OAL) x1
			WS 022-S (WEEP SEAL) x1
			WT 006 (SEAL, 19mmOD, DOUBLE LIP WITH SPRING, 5mm WIDE, NITRILE) x1
			WTA 007 (BALL BEARING WITH SEALS) x1
			WTA 029 (SEAL, 29mm OD, DOUBLE LIP WITH SPRING, 5mm WIDE, NITRILE) x1