

Warthog Tool Kit Contents

WG 612	WGA 612	WGR 612	WGR-U 612	WH 612	WHA 612
BJ 105 (Tool) x1	BA 481 (Tool, Bearing Removal) x1	SC287 105 (2-1/2 Wrench) x1	WGR 180 (PIN, WITH RING, SHAFT LOCKING) x1	BN18 199 (5/8" Rubber Cap) x2	BA 481 (Tool, Bearing Removal) x1
HC 064 (Fill Tube) x1	BJ 105 (Tool) x1	WGR 180 (PIN, WITH RING, SHAFT LOCKING) x1	WGR 181 (PRESS TUBE, REMOVAL) x1	BN18 200 (Tube, Heavy Wall, Clear, 5/8in, 4.0inL) x1	WGR 186 (HP SEAL PULLER) x1
	WGR 183 (TOOL, HEX) x1	WGR 181 (PRESS TUBE, REMOVAL) x1	WGR 182 (PRESS TUBE, INSTALLATION) x1	TJ 064 (FILL TUBE) x1	WHA 105 (TOOL, SEAL INSTALL, 4.0OAL) x1
	WGR 184 (TOOL, INSTALLATION, HP SEAL) x1	WGR 182 (PRESS TUBE, INSTALLATION) x1	WGR 183 (TOOL, HEX) x1	WH 105 (TOOL, SEAL INSTALL, ALUM, 4.0OAL) x1	WHR 183 (TOOL, HEX) x1
	WGR 186 (HP SEAL PULLER) x1	WGR 183 (TOOL, HEX) x1	WGR 184 (TOOL, INSTALLATION, HP SEAL) x1		WHR 184 (TOOL, HP SEAL INSTALLER) x1
		WGR 184 (TOOL, INSTALLATION, HP SEAL) x1	WGR 186 (HP SEAL PULLER) x1		WHR 187 (TOOL, HP SEAL PULLER PIN) x1
		WGR 186 (HP SEAL PULLER) x1			

WHR 612	WHR-U 612	WS 612	WT 612	WV 612-LK
BA 481 (Tool, Bearing Removal) x1	BA 481 (Tool, Bearing Removal) x1	BN18 198 (Rubber Cap, 3/4in) x1	BA 100 (Retaining Ring Pliers) x1	BA 182 (Head Removal Tool (for Locking Head)) x1
WGR 180 (PIN, WITH RING, SHAFT LOCKING) x1	WGR 180 (PIN, WITH RING, SHAFT LOCKING) x1	BN18 201 (Tube, Heavy Wall, Clear, 3/4in, 4.5inL) x1	WT 105 (TOOL, INSTALLATION, ALUM, 2.5OAL) x1	BA 185 (Loctite, 262 Red .5mL) x1
WGR 186 (HP SEAL PULLER) x1	WGR 186 (HP SEAL PULLER) x1	TJ 064 (FILL TUBE) x1		PL 594 (Warthog CLASSIC (WV) USER MANUAL BOOKLET 5.5 x 8.5) x1
WHR 181 (TOOL, REMOVAL PRESS TUBE) x1	WHR 181 (TOOL, REMOVAL PRESS TUBE) x1	WS 105 (INSTALLATION TOOL) x1		WV 010 (RETAINING RING, SS SPIRAL INT 1.125) x2
WHR 182 (TOOL, INSTALLATION PRESS TUBE) x1	WHR 182 (TOOL, INSTALLATION PRESS TUBE) x1			WV 181 (TOOL, SOCKET WRENCH FOR LOCKING HEAD, WV, WU & BA) x1
WHR 183 (TOOL, HEX) x1	WHR 183 (TOOL, HEX) x1			
WHR 184 (TOOL, HP SEAL INSTALLER) x1	WHR 184 (TOOL, HP SEAL INSTALLER) x1			
WHR 187 (TOOL, HP SEAL PULLER PIN) x1	WHR 187 (TOOL, HP SEAL PULLER PIN) x1			