

ARTWORK INSTALLATION GUIDE

What You Will Need

The artwork is supplied with **two eye screws** attached to the back of the frame.



For installation, you will need:

- 2 wall hooks/screws suitable for your wall type
- 2 wall plugs (rawl plugs) suitable for your wall type
- A drill and appropriate drill bit
- A spirit level
- A pencil
- A measuring tape

Please note: The wall hooks/screws and wall plugs are not included with the artwork. Choose the appropriate type and length according to your wall and the desired hanging position.

Installation Instructions

1. Choose the position

Decide where you would like to hang the artwork. Make sure there is sufficient space and that the wall can safely support it.

2. Position the eye screws



The artwork has two eye screws on the back of the frame.

Determine the desired height and make sure that the two eye screws are positioned at **exactly the same height and perfectly level with each other**.

Use a spirit level to check that they are aligned.

3. Mark the wall

Using the position of the two eye screws as a guide, mark the two corresponding points on the wall with a pencil.

Double-check the measurements and ensure both marks are perfectly level.

4. Install the wall plugs and hooks

Drill two holes at the marked points using a drill bit suitable for your wall type.

Insert the appropriate wall plugs and make sure they are securely fixed in the wall.



Then screw in the two wall hooks/screws. Choose a screw or hook with sufficient length and the appropriate load capacity for your wall and the weight of the artwork.

5. Hang the artwork

Once both hooks are securely installed and perfectly level, carefully place the two eye screws on the back of the artwork onto the corresponding wall hooks.

Make sure that both points are properly engaged and that the artwork is securely supported before releasing it.

Important Safety Information

- Use wall plugs and hooks/screws suitable for your specific wall type.
- Ensure that the fixings are appropriate for the weight of the artwork.
- Do not hang the artwork from a single fixing point.
- Check that both hooks are securely fixed before mounting the artwork.
- If you are unsure about the appropriate wall fixings or installation method, consult a qualified professional.

Care Instructions

Handle the artwork with clean, dry hands and avoid touching the photographic print.

Keep the artwork away from excessive humidity, direct sunlight, heat sources, and sudden changes in temperature.

To clean the frame, gently use a soft, dry cloth. Do not use water or cleaning products directly on the artwork or frame.