



To use this Fitment Guide please print at actual size or 100% scale and cut out the diagram below:



Take the measurement with the vehicle as it sits. You do not need to raise it. If between two sizes select the largest size that fits between the coils, not the one that is too big to fit.



With the sizing diagram cut out laying as flat as possible, slide the cut out into the gap between the coils until it is too large to fit. The largest size that fits between the coils is the size for your vehicle.



Scan this QR Code to go to the Coil SumoSprings page where you can order your size Coil SumoSprings

