FOUR-POSITION LOCK SYNCHRO CONTROL

Adjustable Arm Pad

Available on certain models. Move arm pad front to back to desired location.

Height Adjustable Arm

Available on certain models. Push button in and adjust arm to desired height.

Back Tension Adjustment

Standard on all models. Turn knob backward for less tension. Turn knob forward for more tension.

Seat Height Adjustment

Standard on all models. To raise, pull up on lever while not seated until seat is at preferred height. To lower, pull up on lever while seated until seat is at preferred height.

Back Angle Lock/Unlock

Standard on all models.
Turn knob backward to lock.
Turn knob forward to unlock.



Available on certain models.
Pull up on lever and slide seat forward or backward to desired position.



A unit of Kimball International ©2016 Kimball International, Inc. Part No. 2899596



ONE-POSITION LOCK SYNCHRO CONTROL Standard Task Chair

Adjustable Arm Pad

Available on certain models. Move arm pad front to back to desired location.

Height Adjustable Arm

Available on certain models. Push button in and adjust arm to desired height.

Back Angle Lock/Unlock

Standard on all models.
To unlock pull handle out.
To lock push handle in.

Seat Height Adjustment

Standard on all models. To raise, pull up on lever while not seated until seat is at preferred height. To lower, pull up on lever while seated until seat is at preferred height.





