# HITCH® PORTABLE POWER CENTER

## POWER+DATA SOLUTIONS

#### **FEATURES**

- Freestanding, portable USB charging center allows you to charge up to three devices, anywhere
- Includes (3) USB-A ports

## **SPECIFICATIONS**

- · Available in white, light grey, and black
- (3) USB-A ports, 2 amp; Charge up to 3 devices at once
- 11,600 mAh battery capacity; 20w power supply
- Battery: 3.6v, 11.6 amp hours, 41.76 watt hours
- Dead to full charge time: Charges fully in 4.5 hours
- · Charging cord: 5.0 Volts at 4 amps
- Cannot charge devices while unit is being charged
- When charging for the first time, leave unit connected to charger for 4 hours after display indicates full charge, to ensure long lasting battery life
- 6' power cord with 3-prong molded plug; 15 amp
- UL® listed power pack

### MODEL #

NAC04ELPG4HTAW	3¾"D	3¾"W	3¾"H	WHITE
NAC04ELPG4HTAG	3¾"D	3¾"W	3¾"H	LIGHT GREY
NAC04ELPG4HTAB	3¾"D	3¾"W	3¾"H	BLACK













## HITCH® PORTABLE POWER CENTER

## **SPECIFICATIONS**

#### **CHARGING UNIT**

- When charging for the first time, leave unit connected to charger for 4 hours after display indicates full charge, to ensure long lasting battery life
- This step is only necessary for the first time unit is charged
- Cannot charge devices while unit is being charged
- Dead to full charge time: Charges fully in 4.5 hours
- Charging cord: 5.0 Volts at 4 amps

## **BATTERY DISPLAY**

· What does the display indicate?



Flashing lightning bolt: Charging



Solid lightning bolt: Fully charged

 The lightning bolt will only display while unit is connect to the charger









Cells in battery: Charge level (1 cell: 0-25%, 2 cells: 25-50%, 3 cells: 50-75%, 4 cells: 75-100%)



Flashing battery: Battery depleted

- Display will remain lit but you will not be able to charge devices
- This protects the battery from being overdrawn

## **HOW TO STORE**

- · Store in a cool dry place
- $\bullet$  Idea storage temperature range: -20C to 60C
- If left unused for long periods of time (2+ months), unit should be placed on charger 2 hours for every 2 months left unused, this helps keep the battery healthy

## **CLEANING INSTRUCTIONS**

- Wipe with damp cloth; If necessary, a mild detergent may be applied to the cloth
- Do not submerge in water
- · Do not spray unit directly with water or cleaner

### **WARNINGS**

- · Do not disassemble
- Do not penetrate unit with foreign objects
- · Avoid strong impacts
- · Do not crush
- Do not incinerate
- Avoid prolonged exposure to heat above 60°C
- Do not microwave unit, place in high pressure containers, or induction heating devices
- Failure to comply may cause electrical and/or fire hazards resulting in serious injury



