



ELECTRIC DIAGRAM KEY	
F2	Top oven switch
F1	Bottom oven switch
TM	Top oven thermostat
TE	Bottom oven thermostat
LF1	Top oven lamp
LF	Bottom oven lamp
CF	Cooling fan
TL2	Cooling fan thermal overload
C	Top element
G1	Grill Element (Top oven)
S	Bottom element
CIR	Circular element
G	Grill Element
V	Fan
S1	Bottomoven thermostat lamp
S2	Top oven thermostat lamp
TL1	Top oven thermal overload
TL	Bottom oven thermal overload
A	Ignition coil
PA	Ignition switches group
M	Terminal block
T	Earth connection

Bottom oven switch diagram



Top oven switch diagram



	BORSO del GRAPPA 31030 TREVISO - ITALY 0423/9121	
	DATA 14/3/2013	DISEGNATO MILANI M.
DESCRIZIONE IMPIANTO ELETTRICO TWIN CAVITY C9T		
<small>LA FISCHER & PAYKEL APPLIANCE SI RISERVA A TERMINE DI LEGGE LA PROPRIETÀ DEL PRESENTE DISEGNO CON DIVIETO DI RIPRODURLO O COMUNICARLO SENZA SUA AUTORIZZAZIONE.</small>		CODICE 1132174