RIB HANDLER

REQUIREMENTS	FEATURES & BENEFITS
REQUIREMENTS	Clamp made of high-strength material for positioning the ribs comprising the supporting arches for tunnel construction.
Rib Handler: No special requirement.	

Description: With this attachment you can mount arches in tunnels safely and efficiently. The grab can tilt up to 46°, and rotate 65°. What's more, set-up is quick and easy.

TECHNICAL SPECIFICATIONS								
Description	Part Number	Capacity (kg)	Tilting capacity	Rotation	Weight (kg)	First Use Installation Time		
Rib Handler, 4.0 t	7421817	4000	46°	± 65° manual	740	None		

COMPATIBILITY CHARTS											
		Rotary Telehandlers					i	Ī	i		
Description	Part Number	TR40.180	TR50.180	TR50.210	TR50.250	TR60.210	TR60.250	TR70.260	TR60.300	TR60.350	TR60.390
Rib Handler, 4.0 t	7421817	Х	Х	Χ	Х	Х	Χ	Х	Х	Х	Х

GET IN TOUCH WITH US TODAY!

Click one of the following links:



Request a quote 2



Schedule a demo 🗵



Find a dealer ☑

