






PAIN



GAIN


Carry SoftExo



FEATURES



Tilting behaviour



Force distribution



Stabilization



Hollow back behaviour



Safety Relief Balance





Rotation control





SIZES



Support belt Zone

TIP:
The further forward you attach the support belt to the marked area, the stronger the support effect



1



TIP:
The number that is hidden indicates the setting e.g. here the 3



Size 1

0	61 cm -71 cm
1	71 cm -87 cm
2	87 cm -94 cm
3	94 cm -100 cm
4	100 cm -108 cm
5	108 cm -114 cm
6	114 cm -120 cm

Size 2

0	73 cm -83 cm
1	83 cm -97 cm
2	97 cm -104 cm
3	104 cm -110 cm
4	110 cm -116 cm
5	116 cm -124 cm
6	124 cm -130 cm
7	130 cm -136 cm
8	136 cm -142 cm




FIRST-TIME ADJUSTMENT



Support belt Zone




PRESS



Scan me



QUICK-START



Power!



STRETCHING




1 Hands



2 Legs

3 Neck

4 Back



5 Chest



HUNIC GmbH
Bergerweg 51
72270 Balingen
www.hunic.com

FOLLOW US!



hunic_de



HUNIC.SoftExo



@hunic-softexo



HUNIC GmbH



hunic_de