

TECHNICAL DATA SHEET

LCD CLEANER SPRAY



Features:

It is intensely acting cleaning foam, which It is an intensive cleaning foam that, thanks to its balanced combination of cleaning and care components, dissolves deeply penetrated dirt. It cleans oil, nicotine, coal dust and other residues on LCD and touchscreens, monitors, cables, keyboards, printers, scanners, copiers and desks.

- Easy to use
- Dissolves even dried dirt
- Eliminates nicotine covers
- Excellent depth effect
- Removes insect remains

Usage:

Shake well before use. Spray a small amount of cleaner on a cloth and clean dirty surface.

Special instructions:

It contains combustible constituents. Use only in well-ventilated areas. Keep away from sources of ignition. In the consumption of multiple cans in one place there is a danger of formation of explosive gas-air mixtures. Do not smoke, eat or drink during spraying.

Durability and storage:

We guarantee a life span of 24 months in its original unopened packaging, at a storage temperature of -5 $^{\circ}$ C to +30 $^{\circ}$ C.

 Art Nr.
 Content:

 W 170 110
 400 ml

WINKEL GmbH - Lisztstraße 1 - 53881 Euskirchen - Germany - Tel.: +49 2251 77 69 400-401 - Fax: +49 2251 77 69 402 - E-Mail: info@winkelgroup.de