



APARTMENT HOUSE INTERCOM (ROOMSTATION) DP-SS



www.commax.com

COMMAX

COMMAX Co., Ltd

CONNL SmartHome & Securi

- Thank you for purchasing COMMAX products.
 - Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow
 instructions to use a product exactly.
 - The company is not responsible for any safety accidents caused by abnormal operation of the product.

www.safemag.ru

1. CONTROLS AND FUNCTIONS



- 1 HANDSET
- 2 HOOK S/W
- ③ DOOR RELEASE BUTTON
- (4) SPRING CORD

2. OPERATION INSTRUCTION

- 1. Hear a call sound from receiver 1 When visitor press the call button on the doorstation
- 2. Converse with visitor after raise up handset
- 3. After ascertain the visitor, press the door release button (3) to open door

NOTE : No need to connect extra power by reason of it's supplied power source from doorstation

3. WIRING DIAGRAM



www.safemag.ru

4. INSTALLATION

- 1) Please attach a bracket on the wal correctly with screw.
- 2) After the attachment of bracket, please Adjust the groove of the product with a Bracket and then pull it down.





COMMAX Co., Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept. : Tel.; +82-31-7393-540~550 Fax.; +82-31-745-2133 Web site : www.commax.com

Printed In Korea / 2011.06.105

www.safemag.ru