## **Acoustic Panelling Cleaning & Maintenance Guide**



Regular cleaning of the panels is recommended to keep them looking good and lasting for years.

The easiest and most effective way to do this is to use a lint-free cloth. Lightly dust the panels making sure you regularly turn the cloth to ensure a clean surface is used so that dust isn't just transferred to another area.

You can also dampen the cloth slightly with a small amount of warm water so that the cloth is damp to the touch and not wet – this will help it catch any dust.

To remove dust from the felt grooves on the panels we recommend using a soft-brush nozzle attached to a hoover. If using this method, make sure that only the brushes touch the panel and not the plastic attachment as this could leave scratches and marks on the natural wood veneer.

For any visible stains or spots a mild wood cleaner can be used. This must be diluted and a small amount added to a lint-free/microfibre cloth or soft sponge — never directly to the wood. Gently blot or wipe the stained area take care not to use too much pressure to avoid damaging the wood finish. Wipe off any excess moisture with a dry cloth and allow to dry naturally.

<u>Never</u> use household or abrasive cleaners on the wood panelling.