

Floor Sensors

Aube AC112 flexible floor sensor

- Can be used with TH114 and TH115 Series thermostats
- Cable lengths: 10 ft./3 m (AC112-01) and 50 ft./15 m (AC112-03)
- Flexible wire casing



MODELS

- AC112-01** 10 ft./3 m
- AC112-03** 50 ft./15 m

Aube AC130 rigid floor sensor

- Can be used with TH114 and TH115 Series thermostats
- Cable lengths: 10 ft./3 m (AC130-01)
- Rigid wire casing




MODELS

- AC130-01** 10 ft./3 m

RESISTANCE CURVE

°C	Ω	°F
40	5 325	104
35	6 530	95
30	8 056	86
25	10 000	77
20	12 493	68
15	15 714	59
10	19 903	50
5	25 395	41
0	32 651	32
-5	42 317	23
-10	55 304	14



Thermistor (10 kΩ @ 25°C or 77°F)

