


XIII. Repair Parts (continued)



Key No.	Description	Part Number											
		080 -02	080 -27	105 -02	105 -27	150 -02	150 -27	210 -02	210 -27	285 -07	150 -70	210 -70	285 -70
5A	Sage2.X (Programmed) Repair Kit	106191-01									106191-02		106191-03
5B	Programmed Display Repair Kit (with Mounting Hardware)	106217-04											
5C	Repair Transformer Kit	106034-01											