


Residential Replacement Parts List

Spark Ignition

POWER VENTED MODELS: NATURAL OR LP GAS



Ref. No.	Part Description	Qty. Req.	Part Number	
1.	Gas Control Valve	1	(NAT) SP11652B (LP) SP11652C	
2.	Assembly, Control Enclosure	1	N/A	
3.	Transformer	1	SP11787	
4.	On/Off Switch	1	SP10778	
5.	Assembly, Power Cord	1	AM36917	
6.	Thermostat Bracket	1	AM37830	
7.	Composite Edge Grommet	1	AP10780-1	
8.	Ignition Control	1	SP10763C	
9.	Vinyl Vacuum Tubing	1	AP10723-2	
10.	Vacuum Switch	1	SP11875	
11.	Thermostat	1	SP12390	
12.	Burner	1	(40 Gal NAT) AM38380C (40 Gal LP) AM38379C (50 Gal NAT) AM38380B (50 Gal LP) AM38379B (75 Gal NAT) AM38140 (75 Gal LP) AM38142	
13.	Burner Supply Tube	1	N/A	
14.	Inverted Flare Nut	1	AP10691-2	
15.	Pilot Supply Tube	1	N/A	
16.	Ignitor Cable	1	SP8828D	
17.	Pilot / Electrode Assembly	1	(before September 1998: NAT) SP10764B (before September 1998: LP) SP10764C (after September 1998: 40/50 Gal NAT) SP12049B (after September 1998: 40/50 Gal LP) SP12049C (after September 1998: 75 Gal NAT) SP12049D (after September 1998: 75 Gal LP) SP12049E	

To place your order call 1-800-621-5622; fax 1-800-535-9538