



**Indoor sensor**

- Use with basic heating control Model 2871.0US
- Model 2871.2US**

	Wt [lb]	Quantity	Part No	DG
	0.108	1	<b>16016</b>	4



**Multiple outdoor sensor**

- For up to (4) basic heating controls to share a single outdoor sensor
- Use with basic heating control Model 2871.0US

Components

10kΩ thermistor

**Model 2871.3US**

	Wt [lb]	Quantity	Part No	DG
	0.009	1	<b>16020</b>	4



**Zone control**

- Suitable for zone valve Model 2837.1US, 2837.2US, 2837.3US, digital thermostat Model 2874.5US, powerhead Model 2877.7, thermostat heat/cool non programmable Model 2878.6, thermostat heat/cool programmable Model 2878.7, thermostat multistage heat/cool programmable Model 2878.8

- Zone wiring and switching center

Components

Circuit board, 24 VAC transformer

**Model 2874.7US**

Zones	Wt [lb]	Quantity	Part No	DG
4	3.632	1	<b>18060</b>	4
6	5.653	1	<b>18062</b>	4



**RABS - Control unit**

- Use only with Radiant Auto-Balancing System
- Supports up to 8 thermostats and 12 powerheads

Components

Supply sensor, ribbon cable (large)

**Model 1250US**

V	Wt [lb]	Quantity	Part No	DG
120 VAC	1.112	1	<b>17040</b>	4

New



**RABS - Powerhead**

- Use only with Radiant Auto-Balancing System
- Up to 12 per control unit

Note

Required for proper function of RABS

**Model 1250.1US**

V	Wt [lb]	Quantity	Part No	DG
24 VDC	0.194	1	<b>17045</b>	4

New