
## © COLD SHOE Ouick Start Guide





- 1 1/4" screw
- 2 Damping screw 3 Arri pin lock
- 4 Locking knob
- 5 Fixing knob
- 6 Cold shoe

- 7 1/4" thread 8 Allen wrench



Loosen or tighten the damping screw with the supplied allen wrench. The platform can rotate 180°







## © elgato

Elgato, a division of: Corsair Memory Inc., 115 North McCarthy Blvd.

Milpitas, CA 95035, USA Corsair Components Limited, 1020 Eskdale Road,

Winnersh Triangle, Wokingham, RG41 5TS, UK Corsair Memory BV, Wormerweg 8, 1311 XB, Almere, Netherlands

2019-2022 Corsair Memory Inc. All rights reserved. Elgato and the Elgato logo are trademarks of Corsair Memory Inc, registered in the U.S. and other countries

Part: 51AAR9902









