



MONTERINGSANVISNING /
INSTALLATION INSTRUCTIONS / MONTAGEANWEISUNG


UKV 100

MAV SE/GB/DE 0622-2
UKV 100

611182

Utjämningskäril för värmesystem / Buffertank for heating
systems / Puffer Speicher für Heizsysteme

Mått / Dimensions / Maße



Tekniska data / Technical specifications / Technische Daten

Volym / Volume / Volumen	liter	100
Max driftstryck / Max operating pressure / Max.-Betriebsdruck	bar	6
Max temperatur / Max temperature / Max.-Temperatur	°C	95
Vikt / Weight / Gewicht	kg	31

CZ

NIBE CZ
V Zavetri 1478/6
CZ-170 00 Prague 7

Tel: 0266 791 796
Fax: 0266 791 796
E-mail: centrala@nibe-cz.com
www.nibe.com

DE

NIBE Systemtechnik GmbH
Am Reiherpfahl 3
D-29223 Celle

Tel: 05141/7546-0
Fax: 05141/7546-99
E-mail: info@nibe.de
www.nibe.de

DK

Vølund Varmeteknik
Filial af NIBE AB
Brogårdsvej 7, 6920 Videbæk

Tel: 97 17 20 33
Fax: 97 17 29 33
E-mail: info@volundvt.dk
www.volundvt.dk

FI

NIBE – Haato
Valimotie 27
01510 Vantaa

Puh: 09 - 274 697 0
Fax: 09 - 274 697 40
E-mail: info@haato.com
www.haato.fi

GB

NIBE Energy Systems Ltd.

Tel: 08 45 095 1200
Fax: 08 45 095 1201
E-mail: info@nibe.co.uk
www.nibe.co.uk

NL

NIBE Energietechnik B.V.
Postbus 2
4797 ZG WILLEMSTAD NB

Tel: 0168 477722
Fax: 0168 476998
E-mail: info@nibeboilers.nl
www.nibeboilers.nl

NO

NIBE AB
Jerikoveien 20
1067 Oslo

Tel: 22 90 66 00
Fax: 22 90 66 09
E-mail: info@nibe.se
www.nibe-villavarme.no

PL

NIBE-BIAWAR Sp. z o. o.
Aleja Jana Pawła II 57
15-703 BIAŁYSTOK

Tel: 085 662 84 90
Fax: 085 662 84 14
E-mail: sekretariat@biawar.com.pl
www.biawar.com.pl



NIBE AB Box 14
Järnvägsgatan 40
SWEDEN SE-285 21 MARKARYD

Tel: +46 - (0)433 - 73 000
Fax: +46 - (0)433 - 73 190
E-mail: info@nibe.se
www.nibe.com