



# MANUAL






XB401 **TITAN**

Gebruiksaanwijzing  
Gebrauchsanweisung  
Mode d'emploi  
Bruksanvisning  
Brugsvejledning


Käyttöopas  
Užívateľská príručka  
Používateľská príručka  
Εγχειρίδιο χρήσης  
دەستەسازمەسەلە



# 1 SPECIFICATIONS

-  24.000 mAh Li-ion / 88.8Wh
-  1x USB-C Power Delivery 60W  
2x USB-C Power Delivery 30W
-  185x90x25 mm
-  626 grams
-  1x Built-in USB-C Power Delivery 60W cable  
1x Manual

# PRODUCT OVERVIEW 2




- In/Output USB-C PD 60W ①
- USB-C PD 30W ②
- USB-C PD 30W ③
- Power Button ④
- LED Power Indicator ⑤
- Built-in USB-C PD Cable ⑥
- Official Xstorm Label ⑦

When using all outputs:

- ① 60W ② ③ Share 20W

### 3 CHARGING YOUR DEVICE




#### COMPATIBLE DEVICES



- 3A** Connect one end of the charging cable to one of the outputs of the Power Bank and the other end to the input of your device.
- 3B** For Charging USB-C Ultrabooks use output 1 (USB-C PD 60W).


### RECHARGING THE POWER BANK 4



- 4A** Connect one end of the built-in charging cable to output 1 of the Power Bank and the other end to a wall charger.
- 4B** For the fastest charging possible use a 60W USB-C PD charger. This will fully recharge the Power Bank within 2 hours.

## 5 LED POWER INDICATOR

## IN THE BOX 6



- 5A** Press the Power Button once to display the battery level remaining in the Power Bank via the LED display.
- 5B** The display shows the remaining battery percentage between 0% (empty) and 100% (fully charged).
- 5C** The charging icon will flash when the Power Bank itself is being recharged.




1



2



3



# EN - ENGLISH

---

## 1 SPECIFICATIONS

## 2 PRODUCT OVERVIEW

## 3 CHARGING YOUR DEVICE

**3.A** Connect one end of the charging cable to one of the outputs of the Power Bank and the other end to the input of your device.

**3.B** For Charging USB-C Ultrabooks use output 1 (USB-C PD 60W).

## 4 RECHARGING THE POWER BANK

**4.A** Connect one end of the built-in charging cable to output 1 of the Power Bank and the other end to a wall charger.

**4.B** For the fastest charging possible use a 60W USB-C PD charger. This will fully recharge the Power Bank within 2-3 hours.

## 5 LED POWER INDICATOR

**5.A** Press the Power Button once to display the battery level remaining in the Power Bank via the LED display.

**5.B** The display shows the remaining battery percentage between 0% (empty) and 100% (fully charged).

**5.C** The charging icon will flash when the Power Bank itself is being recharged.

## 6 IN THE BOX

# DK - DANSK

---

## 1 SPECIFIKATIONER

## 2 PRODUKTOVERSIGT

## 3 OPLADNING AF DIN ENHED

**3.A** Tilslut den ene ende af opladningskablet til en af Power Banks udgange og den anden ende til indgangen på din enhed.

**3.B** Til opladning af USB-C-bærbare computere skal du bruge udgang 1 (USB-C PD 60W).

## 4 GENOPLADNING AF POWERBANKEN

**4.A** Tilslut den ene ende af det indbyggede opladningskabel til udgang 1 på Power Bank og den anden ende til en vægoplader.

**4.B** For at opnå den hurtigst mulige opladning skal du bruge en 60W USB-C PD-oplader. Dette vil oplade Power Bank fuldt ud inden for 2-3 time.

## 5 LED STRØMINDIKATOR

**5.A** Tryk på Power-knappen én gang for at få vist det resterende batteriniveau i Power Bank'en via LED-displayet.

**5.B** Displayet viser den resterende batteriprocent mellem 0 % (tomt) og 100 % (fuldt opladet).

**5.C** Opladningsikonet blinker, når selve Power Bank'en er ved at blive genopladet.

## 6 I KASSEN