



DATA SHEET

 For waterfilled

Valve type 130

Type:	Manual angle valve.
Thermostat:	No.
Mounting:	½" thread into the radiator and ½" inside thread toward the wall.
Mounting distance:	From bottom of the radiator to center of the inside thread toward the wall is 40 mm. From center of the radiator thread to back of valve toward the wall is 50 mm. spacer are included in the box to increase the distance with 11 mm if nessesary.
Included into the box: increase	Plastic pipe coverings with rosettes in the same surface as the valve. The pipe coverings are 50 mm and the rosettes are Ø60 mm. Also 4 spacer to
Remarks:	The mounting connection with the outside thread that goes into the radiator is chrome on the black and white valves.