







TWA-A
for Danfoss RA valves





TWA-V
For Danfoss RAV/VMT valves




TWA-L
For Danfoss RAWL valves



TWA-K
For valves with
Heimeier/MNG/Oventrop
M30 x 1.5 connection




NO



*) 24 V Class II transformer (SELV)
**) 230 V max. 3 A pre-fuse

IP 41







INSTRUCTIONS

TWA NC



088F0248

088F0248



TWA-A
for Danfoss RA valves





TWA-V
For Danfoss RAV/VMT valves




TWA-L
For Danfoss RAVL valves



TWA-K
For valves with
Heimeier/MNG/Oventrop
M30 x 1.5 connection



NC



*) 24 V Class II transformer (SELV)
**) 230 V max. 3 A pre-fuse

IP 41

