

ZEN

Rengørings vejledning Cleaning instructions



ENG

Maintenance

Clean your Zen product with a liquid, gentle, citric acid-based cleanser. After cleaning always rinse the product set thoroughly with clean water and dry with a soft cloth. Do not use cleaners containing hydrochloric acid, acetic acid, chlorine or other harmful, aggressive agents. Do not use cleaners containing phosphoric acid. Similarly, do not use abrasive sponges or other rough cloths.

Warranty conditions

Your receipt or invoice is your only valid proof of warranty, store it carefully. In the event of a defect with your product contact your dealer. The warranty on your product covers manufacturing defects. Damage or malfunction caused by poor water quality (limescale, sand, metals etc.) are not covered by the warranty. Use a filter and / or descaling device. In the event of misuse or poor installation, the manufacturer cannot accept liability and the warranty is voided. The warranty is at point of purchase. Under no circumstances will goods be collected from you or repairs conducted on site.

DA

Vedligeholdelse

Rengør dit Zen produkt med et flydende, blidt, citronsyrebaseret rengøringsmiddel. Efter rengøring skylles brusestangssættet grundigt med rent vand og tørres med en blød klud. Brug ikke rengøringsmidler, der indeholder saltsyre, eddikesyre, klor eller andre skadelige, aggressive stoffer. Brug ikke rengøringsmidler, der indeholder fosforsyre. Brug heller ikke slibende svampe eller andre former for grove klude.

Garantibetingelser

Din kvittering eller faktura er dit eneste gyldige garantibevis. Gem det derfor omhyggeligt. Kontakt din forhandler i tilfælde af en defekt ved dit produkt.

Garantien på dit produkt dækker fabriktionsfejl. Skader eller funktionsfejl forårsaget af dårlig vandkvalitet (kalk, sand, metaller osv.), er ikke dækket af garantien. Brug et filter og / eller en afkalkningsenhed. I tilfælde af misbrug eller forkert installation kan producenten ikke påtage sig ansvar, og garantien bortfalder. Garantien gælder fra købstidspunktet. Under ingen omstændigheder vil varen blive indsamlet hos køber eller udført reparationer hos køber.