

Installation Instructions


Instrucciones de instalación, Instructions d'installation, Installationsanleitung, إرشادات التركيب

Installatie-instructies, Instruções de instalação, Installatie-instructies,


設置手順説明, Οδηγίες εγκατάστασης




Product Code: [4L3/3000 - 3003]



Please Visit
<https://4liteuk.com>
 downloads for our warranty
 and translations



Product Code	Description	Rated Wattage
4L3/3000	T8 LED Tube CCT 600mm	5/9
4L3/3001	T8 LED Tube CCT 1200mm	9/17.5
4L3/3002	T8 LED Tube CCT 1500mm	12/22
4L3/3003	T8 LED Tube CCT 1800mm	12/24



Wiring diagram A (With Magnetic Ballasts) : Operating instructions: (Diagram)
 Only compatible with ferromagnetic ballasts used with LED starter and LED replaceable ballasts.
 Not compatible with ballasts operating with electronic ballasts

- ①、Magnetic Ballasts
- ②、LED Tube
- ③、Take away Starter
- ④、Replace LED starter

Ansell Electrical Products
 Unit 6B, Stonecross Industrial
 Park,
 Yew Tree Way,
 Warrington,
 WA3 3JD

Ansell (Sales & Distribution)
 Unit 2, M2 Business Park,
 Duncrue Street,
 Belfast,
 BT3 9AQ

Ansell (Sales & Distribution) Republic of Ireland Limited
 Unit G1, Block G,
 Calmount Park, Calmount Avenue
 Dublin 12,
 D12 TH56

Warrington Tel: +44 (0)1942 433333

Belfast Tel: +44 (0)2890 773750

International Tel: +44 (0)1942 433343

Spain Tel: 00 34 938 005642

B (AC Mains) : Operating instructions: (Diagram)

220-240V

