



AVK TENSILE SOCKET JOINTS FOR PE PIPES

Mounting instruction / Montagevejledning
Einbauanleitung / Instruction de montage

OPTION 1

1A.

| | |
|-------|---|
| PE | ✓ |
| PVC | ✗ |
| DI | ✗ |
| STEEL | ✗ |

2A.

90°

3A.

20° - 30°

OPTION 2

1B.

| | |
|-------|---|
| PE | ✓ |
| PVC | ✗ |
| DI | ✗ |
| STEEL | ✗ |

2B.

90°

3B.

4.

A**

5.

6.

X < 5 mm

* 05-025-54002
05-032-54002
05-040-54002
05-050-54002
05-063-54002

! Only SDR 11

A

** DN 25 - Ø32 mm = 66 mm
DN 32 - Ø40 mm = 75 mm
DN 40 - Ø50 mm = 91 mm
DN 50 - Ø63 mm = 111 mm


Mounting instruction

Montagevejledning / Einbauanleitung /
Instruction de montage

AVK Tensile socket joints for PE pipes



9632500129_rev AA



www.avkvalves.eu