












**IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.**

MODEL : B580

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
TU580-B / Back	TU580-S / Seat	TU058 / Right & Left Arm
(4)x1	(5)x1	(6)x1
		
TU001-Mechanism	TU026-Gas Lift	TU005-Five Star Base
(7)x5	<p>(A)X6  M6X30 Arm Screws</p> <p>(B)X4  M8X22 Mechanism Screws</p> <p>(C)X4  M8X30 Back Bar Screws</p>	
		
TU015-Casters		



**Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.
This chair is only intended for sitting. Any other use will void the warranty.**

