



R&B WIRE PRODUCTS, INC.  
YOUR TRUSTED PARTNER SINCE 1946

## ASSEMBLY INSTRUCTIONS

### MODEL RB51PL Mobile Laundry Scale



#### TOOLS REQUIRED:

- (2) 7/16 wrenches or sockets
- (1) 1/2 wrench or socket



1 person assembly

#### STEP 1

Set base upside down and insert caster stem into base leg. Insert full-thread hex bolt into each leg hole, and secure with nylon locking nuts facing toward inside of unit. Repeat for remaining casters.



#### STEP 2

Turn base over so wheels are down. Attach handle bar to base by removing pre-installed upper base bolt, threading it through handle bar and re-inserting into original hole in base. Do not completely tighten until bottom bolt has been inserted.



#### STEP 3

Insert partial-thread hex bolt through bottom hole of handle bar and through base. Secure with nylon lock nut. Tighten all bolts and nuts on handle bar.

#### WARNING



- Never allow anybody to ride in or on cart.
- Always proceed slowly.
- Be sure wheels roll free and turn easily.
- Place all loads in center of basket for balance.
- Maximum capacity per basket: 100 pounds.

#### HARDWARE INCLUDED (Not to scale)



x2 Partial-thread bolts



x14 Nuts



x8 Full-thread bolts



x4 Flat washers





R&B WIRE PRODUCTS, INC.

YOUR TRUSTED PARTNER SINCE 1946

## ASSEMBLY INSTRUCTIONS

### MODEL RB51PL Mobile Laundry Scale pg 2



#### STEP 4

Repeat steps 2 and 3 on other side of base to attach second handle bar.



#### STEP 5

Thread the scale's pre-installed bolts through holes in top of base. From the bottom of the base, attach a washer followed by a nut on each of the 4 bolts. Secure with 7/16 wrench.

**NOTE:** It may be necessary to loosen pre-installed nuts on bottom of scale to align the bolts with the holes in base. Be sure to re-tighten nuts if this is done.



#### STEP 6

Place the Poly Tub between the arms of the handles and onto the scale.

**NOTE:** Be sure that handle bars do not rest on sides of Poly Tub. If they do, gently pull handles away from tub until a small gap is created. This will assure that the scale will register properly. If scale needs to be zeroed out, there is a small dial on right side that can be turned until the indicator reads zero.

**Your Mobile Laundry Scale is ready for use.**

