INSTRUCTIONS FOR MODELS TOOLS AND SUPPLIES S-2005-HB Thread Seal Adjustable Wrench Tape MPORTANT A Be sure to read instructions thoroughly before beginning installation. Do not overtighten any connections or damage may occur. This showerhead has an operating range of 20-80 psi. STREAM SAFETY TIPS 🕑

NEED HELP?

For additional assistance or service please contact:

SPEAKMAN® Company 400 Anchor Mill Road New Castle, DE 19720

customerservice@speakmancompany.com

www.speakmancompany.com

92-S-2005-HB-R1



Apply Thread Seal Tape to the outlet side of shower arm in a clockwise direction.

Thread Showerhead onto shower arm by turning it in a clockwise direction. Tighten with adjustable wrench. Turn water supply on and check for



ROUGH IN DIMENSIONS





Specifications: Inlet: 1/2" NPT FEMALE