



SEARPLATETM GRIDDLE

USER GUIDE

 **BREED[®]**

HOW TO USE THE SEARPLATE™ GRIDDLE



STEP 1

Start your fire using the log cabin method, and gradually add fuel to make a large flame. Allow the fire to burn and build a bed of coals for at least an hour before placing the griddle onto the fire pit.

STEP 2

Position the SearPlate™ Griddle over the fire pit once the flame tips are **BELOW** the fire pit rim. Using two people, lower the griddle onto the fire pit and turn the handles into a downward position. Level the griddle by nudging the low side up with a glove or spatula, allowing the leveling tabs to slide along the fire pit rim. Continue until the griddle is level to the eye.



STEP 3

Allow the griddle to heat for 5-10 minutes or until it reaches 450-500°F. Do not overheat the griddle. We recommend starting with a low flame and adding logs when more heat is needed.



STEP 4

Remove the SearPlate Griddle immediately after the cook is complete. Using two people, raise the handles and lift. Rest the griddle on the SearPlate Stand or a noncombustible surface nearby where it won't be in the way or a tripping hazard.



Scan to watch and learn more about the SearPlate Griddle.

BREEO TIP

Test the heat by doing a water test: Sprinkle water onto the griddle, if it pops and sizzles, you're ready to go!



FOR YOUR SAFETY

Always practice safety first when using the SearPlate™ Griddle.

While using the SearPlate Griddle, exercise the same precautions you would with any open fire. Never leave your SearPlate Griddle unattended, especially around children and pets.

Remove the SearPlate Griddle immediately after the cook is complete. If the griddle is left on the heat for extended periods of time, it may cause the oil to burn off the griddle and rust the carbon steel.

After removing the SearPlate Griddle, do not place it on any combustible surfaces and keep it away from children and pets.

MAINTAIN THE SEARPLATE™ GRIDDLE

STEP 1

Clean the SearPlate™ Griddle after it's removed from the fire pit and still warm to touch. Use a paper towel or a flat-edged spatula to clean the griddle and scrape off any residue or grease.

STEP 2

Oil the SearPlate Griddle by massaging a thin layer of food-grade oil into the metal with a clean paper towel. We recommend using Canola, Avocado, or Grapeseed Oil. Wipe any excess oil off, and the griddle is ready for the next burn. Please note that we oil the top of the SearPlate Griddle before we ship it. The bottom is left unoiled intentionally and may have some discoloration, which will not affect its performance.

STEP 3

Place the griddle on the SearPlate Stand or any noncombustible surface to completely cool.

STEP 4

Store the SearPlate Griddle and/or SearPlate Stand in a dry space until your next use.





Breeo, LLC warrants to the original purchaser that the Breeo Fire Pits and Accessories are free from workmanship and material defects during the lifetime of the original purchaser. In addition Breeo, LLC warrants no rust through or burn through for a period of five (5) years from purchase. If a product is covered by this limited warranty, Breeo, LLC, at its option, will repair or replace with a new product free of charge, excluding any applicable shipping and handling charges. If the product being warranted has been discontinued, the replacement product will be of equal or similar value. Altering any Breeo product, or using the product in any way other than the intended use, will void this Lifetime Warranty. Except as provided above, no warranty is offered on rust, paint or finishes due to being made with material with potential for corrosion. Steel products will develop a natural iron oxide patina over time.

Breeo, LLC's liability and obligation is limited to repair or replacement of the product, at their option. The purchaser must provide Breeo, LLC with photos of the product's defects for evaluation. Upon approval of warranty, Breeo, LLC will issue a return for repair, or return for exchange of the defective product.

This warranty does not cover damage or product failure caused by normal wear and tear, accident, misuse, negligence, tampering, modifications, act of war, overloading, improper attachment, improper maintenance, or failure to maintain. Breeo, LLC is held harmless for any injury or death caused by the misuse of this product. This warranty does not cover damage caused by proper or improper use of our products to any surrounding surfaces, structures, or furnishings. This includes, but is not limited to, discoloration or damage to a patio or deck surface, furniture, house, or any other structure.

This warranty gives you specific legal rights providing said product is put to its proper designated use.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO ORAL AGREEMENT, GUARANTEE, PROMISE, REPRESENTATION OR WARRANTY SHALL BE BINDING. IN NO EVENT WILL BREEO, LLC BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES EVEN IF BREEO, LLC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND EVEN IF BREEO, LLC HAS KNOWLEDGE THAT FAILURE TO PERFORM COULD CAUSE CONSEQUENTIAL ECONOMIC LOSSES. IN ANY EVENT, CUMULATIVE DAMAGES FOR BREACH OF THIS WARRANTY WILL BE LIMITED TO THE AMOUNT ACTUALLY PAID TO BREEO, LLC FOR THE PRODUCT. THIS PARAGRAPH SHALL APPLY TO ALL ACTIONS RELATED TO THE PRODUCT, WHETHER BASED ON TORT, CONTRACT OR OTHER THEORIES. THE PURCHASER ACKNOWLEDGES THAT THIS PARAGRAPH ALLOCATES THE RISK OF PRODUCT FAILURE BETWEEN BREEO, LLC AND THE PURCHASER, AND THAT THIS ALLOCATION IS REFLECTED IN THE PRICE PAID.



WWW.BREEO.CO

(800) 413-9848

CONTACT@BREEOLLC.COM

