




ASSEMBLY INSTRUCTIONS
37 – DISHWASH
ENTRY/EXIT

- 37-6-0600



CONTENTS:



X 1




X 1




X 2



X 2




X 1




X 1

GRUB SCREWS
PRE FITTED


01



02



03



04

