

Published on Fluke Calibration: US (http://us.flukecal.com)

 $\underline{Home} > \underline{Products} > \underline{Temperature\ Calibration} > \underline{ITS-90\ Temperature\ Standards} > \underline{Resistance\ Bridges} > \underline{1594A/1595A\ Super-Thermometers} > \underline{Printer-friendly\ PDF}$

1594A/1595A Super-Thermometers

Highlights

Thermometry bridge accuracy combined with time-saving features

The Fluke Calibration 1594A and 1595A Super-Thermometers combine the accuracy of complex and expensive bridges with innovative features that simplify measurement processes and provide excellent value. They are accurate enough for the primary lab and economical enough for the secondary lab. With temperature-controlled internal reference resistors, six input channels, a large graphical display, and a multitude of temperature-specific measurement functions, PRT, thermistor and SPRT calibration (0 Ω to 500 k Ω) has never been so easy and economical. And with the built-in Ratio Self-Calibration function, you can verify or calibrate the Super-Thermometer's ratio accuracy in-house with the press of a button—no other single thermometry bridge can do so much, so well!

Super-Thermometer features at a glance

- Calibrate SPRTs, PRTs, RTDs and thermistors (0 Ω to 500 k Ω)
- Accuracy as good as 0.06 ppm (0.000015 °C)
- "Ratio Self-Calibration" verifies and calibrates resistance ratio accuracy
- Automatic zero-power measurements calculate thermometer probe self-heating
- Temperature-controlled internal reference resistors
- Calibrated sensing current lowers overall instrument uncertainty
- Four input channels on the front panel accept sensors under test or external references
- Two dedicated external reference input channels on the rear panel
- Standby current reduces transient effects when scanning between channels
- Channel Select keys turn measurement mode on or off at the touch of a button
- · Sample rates as fast as one second
- USB data transfer and computer control
- Remote view and device control via Ethernet
- Compatible with MET/TEMP II automated calibration software and LogWare II multichannel, real-time data acquisition software

Description

Resistance ratio or absolute resistance measurements: the choice is yours

When your goal is to achieve the highest measurement accuracy possible, you will mostly likely make a resistance ratio measurement (Rx/Rs). The measurement accuracy of the 1595A over typical thermometry ratios (0.25 to 4.0) is as good as or better than 0.2 ppm. And for ratios near unity (0.95 to 1.05), the resistance ratio accuracy of the 1595A is as good as 0.06 ppm. You get the linearity of a traditional resistance bridge with an instrument that is easier to use and a much better value.

Example 1: Using a 25 Ω SPRT with a 25 Ω external reference resistor, the resistance ratio uncertainty of the 1595A at the triple-point of water is only 0.06 ppm (Rx/Rs \approx 1). This becomes significant when considering that the uncertainty of the RTPW measurement is propagated throughout all ITS-90 temperature measurements.

Example 2: The Direct Comparison Method measures the probe under test directly against a calibrated reference SPRT by defining the SPRT as the reference resistor (Rs). Since the ratio $Rx/Rs \approx 1$ over the full temperature calibration range, the uncertainty contribution of the 1595A to the overall measurement uncertainty is no greater than 0.06 ppm. Considering all other influence effects, total measurement uncertainty can be achieved in the sub-mK range.

Although a ratio measurement can produce the most accurate results, it may not always be the most convenient measurement method. Using the temperature-controlled internal reference resistors, the Super-Thermometer can convert an absolute resistance measurement to a temperature unit and display the result in degrees Centigrade, Fahrenheit, or Kelvin, or in Ohms. Each Super-Thermometer includes internal reference resistors of 1 Ω , 10 Ω , 25 Ω , 100 Ω and 10 k Ω that support a variety of PRTs, RTDs and thermistors.

How well a thermometry bridge can measure absolute resistance depends on the bridge's ratio accuracy, as well as the long-term stability and calibration accuracy of its internal reference resistors. To ensure stability and eliminate errors, the internal

reference resistors in the Super-Thermometer are enclosed in an oven that is temperature controlled at 30 °C and stable to within approximately 10 millikelvin. In fact, these precision resistors are controlled so well that within a 24-hour period, their resistance will not change more than 0.25 ppm (equivalent to 0.00006 °C). The one-year absolute accuracy of the Super-Thermometer is 4 ppm (equivalent to 0.001 °C).

Measurement current accuracy is important when evaluating measurement uncertainty due to self heating of the thermometer. The accuracy of the current source in the Super-Thermometer is 0.2% when measuring 25 Ω or 100 Ω PRTs with a typical sensing current level.

Low measurement noise

Measurement noise is caused by electrical noise and other random errors that can negatively influence measurement accuracy. New patent-pending design innovations incorporated into the Super-Thermometer reduce measurement noise and interference to levels that are unprecedented for a digital thermometry bridge. Two identical amplifier/ADC blocks measure Rx and Rs simultaneously. Reversing the sensing current and then averaging the two measurements reduce errors caused by thermoelectric EMFs, current source instability, and electrical noise. To further reduce measurement noise, two parallel ADCs are used in each amplifier/ADC block. Passive and active filters are also utilized to reject the majority of electrical noise and interference. In a typical temperature calibration application, the Super-Thermometer offers uncertainty due to measurement noise as low as 0.00002 °C. Under similar measurement parameters, the noise level of the Super-Thermometer can be as low as a traditional, much more expensive, resistance bridge.

Unprecedented measurement speed

Super-Thermometers offer speeds as fast as one second per measurement (full accuracy with a two second sample rate). You can complete your tests in less time, track temperature changes more accurately, and even evaluate thermal response in sensors. When measuring fixed point temperatures that require the highest levels of accuracy and lowest levels of noise, you have complete control to change the measurement speed to meet your requirements.

Verify ratio accuracy in-house with Ratio Self-Calibration

The 1594A and 1595A feature patent-pending "Ratio Self-Calibration" that enables you to test the accuracy or calibrate the resistance ratio linearity of the Super-Thermometer's measurement circuit – regularly, easily, and without requiring any external devices or special training. The Super-Thermometer performs the Ratio Self-Calibration by automatically combining and switching between the internal temperature-controlled reference resistors to create a resistance voltage divider network. Replacing RX and RS with the resistance voltage divider allows the Super-Thermometer to complete a series of eight resistance ratio tests, from which linearity errors are calculated and accuracy relative to specifications can be verified. See figures 1 and 2 for examples of the resulting report.

Now you can verify accuracy and performance automatically in about thirty minutes, at the touch of a button. Although rare, measurement circuit defects are detected and reported automatically. Through a password-protected procedure, you can choose whether to align the Super-Thermometer by applying the offsets generated by the calibration procedure. No other temperature measurement instrument on the market more fully empowers the metrologist to determine and improve instrument performance.

Ratio Self-Calibration features at a glance

- Automatically test or calibrate the Super-Thermometers' resistance ratio linearity without expensive external equipment
- Detect possible equipment failures before they affect your measurements
- No special operator training required
- Complete the test in approximately 30 minutes
- Extend interval between calibration cycles

Calibrate internal reference resistors, quickly and easily

You can also calibrate the Super-Thermometer's internal reference resistors using the resistance calibration function. This process requires an external standard resistor that is approximately equal in value to the internal reference resistor to be calibrated.

The Super-Thermometer assists you with the calibration through an easy-to-use setup utility. Just specify which internal resistor is to be calibrated, the calibrated resistance value of the standard resistor, and the channel to which the standard resistor is connected. The Super-Thermometer configures the sensing current, disables filtering, and sets the timing parameters to the "precision" settings for consistent results.

Once the calibration is complete, the Super-Thermometer reports the results to the display and gives you the option to write the results to a USB memory device. You can also choose whether or not to adjust the calibration parameters of the internal reference resistor by pressing the password-protected Adjust Resistor function key.

Calculate the effects of self-heating, quickly and easily

When current is passed through a PRT sensor, power is dissipated by the sensing element, causing the sensor to self-heat.

That introduces a small temperature error into the measurement. The error can be estimated by measuring the resistance of the sensor at a given temperature with two different sensing current power levels, nominal current and "double-power" (nominal current). Through linear extrapolation to "zero-power," the resistance value of the sensor can then be estimated as if no current were applied to the sensing element. The temperature error due to self-heating can then be effectively eliminated from the measurement.

Computing a zero-power measurement manually can be time consuming and subject to calculation errors. The Super-Thermometer's Zero-Power Measurement function sets current levels and collects measurement data automatically, calculating the zero-power measurement for you. User-adjustable settings give you full control of the process by allowing you to set parameters such as settle time, measure time, and record result.

View key measurement data in graphic or table formats, on multiple channels -- simultaneously

Suppose you want to see the results of more than one channel simultaneously. The Super-Thermometer includes two measurement viewing modes—graph and table view modes. Select graph mode to graph a single channel or multiple channels simultaneously; set the duration of the graphing window; select automatic centering or enter a fixed value for the vertical center; select automatic scaling; or enter a fixed value for the vertical span. Configure the graph however you like to fit your application. In table mode, the measured value, mean and standard deviation for all channels are displayed simultaneously in a numeric table format. Simply press the function key to toggle between the graph and table views.

Specifications

1594A / 1595A Genera	al Specifications
Measurement capability	4-wire PRT, Thermistor, Resistance, Resistance Ratio
Input resistance range	0 to 500 k Ω
Ratio range	0 to 10
Accepted external RS range	1 Ω to 10 kΩ
Internal RS	1 Ω , 10 Ω , 25 Ω , 100 Ω , and 10 k Ω
PRT conversion types	ITS-90, PT-100, CVD-ABC, CVD-ALPHA, Polynomial
Thermistor conversion types	R(T) Polynomial, T(R) Polynomial
Display units	ratio (RX / RS), K, °C, °F, Ω
Display resolution	0.1 to 0.000001
Sample period	(seconds)1 1, 2, 5, and 10
Statistics	Average, Std Dev, SE of Mean, Max, Min, Difference, Peak-Peak, Delta, N
Front panel channels	Four PRT/Thermistor inputs (channels 2 & 4 can be configured for either RX or RS inputs)
Rear panel channels	Two dedicated reference resistor inputs (RS)
Input terminals	DWF Connector, Tellurium Copper
Data logging to internal memory	80,000 individual time- and date-stamped readings (~6 MB)
Internal real-time clock	Yes
Computer communications	RS-232, USB, IEEE-488, Ethernet
Display type	Full VGA, LCD
User interface languages	English, French, Spanish, German, Russian, Chinese, Japanese

Resistance Ratio Accuracy, 95% Confidence Level, 1-yr		
	1594A	1595A
Ratio: 0.95 to 1.05	0.24 ppm	0.06 ppm

Ratio: 0.5 to 0.95, 1.05 to 2.0	0.64 ppm	0.16 ppm
Ratio: 0.25 to 0.5, 2.0 to 4.0	0.8 ppm	0.2 ppm
Ratio: 0.0 to 0.25	0.2 ppm of 1.0	0.05 ppm of 1.0
Ratio: 4.0 to 10.0	2.0 ppm	0.5 ppm

1594A / 1595A Absolute Resistance Accuracy, 95% Confidence Level, 1-yr

(RS, current)		
0 Ω to 1.2 Ω (1 $\Omega,$ 10 mA)	Greater of 40 ppm or 0.000012 $\boldsymbol{\Omega}$	
0 Ω to 12 Ω (10 $\Omega, 3$ mA)	Greater of 10 ppm or 0.000024 Ω	
0 Ω to 120 Ω (25 $\Omega, 1$ mA)	Greater of 5 ppm or 0.000024 Ω	
0 Ω to 400 Ω (100 Ω , 1 mA)	Greater of 4 ppm or 0.00008 Ω	
0 kΩ to 10 kΩ (10 kΩ, 10 μA)	Greater of 5 ppm or 0.000012 Ω	
10 k to 40 kΩ (10 kΩ, 10 μA)	8 ppm	
40 kΩ to 100 kΩ (10 kΩ, 2 μA)	20 ppm	
100 k Ω to 500 k Ω (10 k $\Omega,$ 1 $\mu A)$	80 ppm	

1594A / 1595A Internal Resistor Stability

	24 hours	30 days
1Ω	5 ppm	10 ppm
10 Ω	0.5 ppm	2 ppm
25 Ω	0.25 ppm	1 ppm
100 Ω	0.2 ppm	1 ppm
10 kΩ	0.25 ppm	1 ppm

1594A / 1595A Temperature Measurement Noise - Typical Performance (standard error of the mean, $^{\circ}$ C)²

25Ω SPRT at 0°C	0.00002
25Ω SPRT at 420°C	0.00006
100Ω PRT at 0°C	0.00001
100Ω PRT at 420°C	0.00003
Thermistor at 25°C	0.000003

1594A / 1595A Measurement Current Accuracy (self-heating)

0.001 mA to 0.005 mA	0.00005 mA
0.005 mA to 0.02 mA	1 %
0.02 mA to 0.2 mA	0.5 %
0.2 mA to 2 mA	0.2 %
2 mA to 20 mA	0.5 %

1594A / 1595A Mechanical Specifications	
Weight	7.5 kg (16.5 lbs)
External Width x Height x Length 432 mm x 153 mm x 432 mm (17 x 6 x 17 inches)	

1594A / 1595A Operating Specifications	
AC power requirements	100V to 230V ±10%, 50/60Hz
Specified operating temperature	15°C to 30 °C
Max operating temperature	5°C to 40 °C
Storage temperature	0°C to 40 °C
Operating relative humidity, 5°C to 30°C	10% to 70%
Operating relative humidity, 30°C to 40°C	10% to 50%
Storage relative humidity	0% to 95%, non-condensing
Operating altitude	3000 m
Warranty period	1 Year
Report of Calibration ³	NVLAP accredited

Models and Accessories

Model Name	Description	
1594A	Super-Thermometer, 0.8 ppm Includes: NVLAP-accredited certificate of calibration User's guide (English, Spanish, French, German, Chinese, and Japanese on CD-ROM) Technical guide (English only on CD-ROM) RS-232 to USB converter cable Regional power cord	
J34A	Accessory	Description
	1994	Verification, Extended Range, 100-500k Ohms,1594A
	2373-DIN	Adapter, Rnd INFO-CON to Spade Lug This adapter is designed for use with the 1594A/1595A Super-Thermometers.
595A	Includes:NVLAPUser's gTechnicRS-232	ometer, 0.2 ppm -accredited certificate of calibration guide (English, Spanish, French, German, Chinese, and Japanese on CD-ROM) al guide (English only on CD-ROM) to USB converter cable al power cord

 $^{^1}$ Two second sample rate required for full accuracy 2 Due to the subjective nature of measurement noise, it is not a guaranteed specification 3 The standard Report of Calibration includes resistance data from 1 Ω to 100 k Ω . A Report of Calibration may be ordered if resistance data from 100 k Ω to 500 k Ω is desired (see model numbers 1994 and 1995 in the ordering information table).

	Accessory	Description
	1995	Verification, Extended Range, 100-500k Ohms,1595A
	2373-DIN	Adapter, Rnd INFO-CON to Spade Lug This adapter is designed for use with the 1594A/1595A Super-Thermometers.
9938	MET/TEMP II temperature calibration software (includes CD-ROM, RS- 232 multiplexer box, AC adapter, and serial cable)	
9935-S	LogWare II, Multi Channel, Single User	
9935-M	Log <i>Ware</i> II, Multi Channel, Multi User	

Accessories common to all models:

Accessory	Description	
Y159X	Kit, 1594/95 Rack Mount	
1594-CASE	Case, 1594/95 Carrying	
1594-HNDL	Kit, 1594/95 Side Carrying Handle	
1594- SIDEHNDL	Kit, 1594/95 Side Carrying Handle	
1594- HNDLCVR	Handle, Cover	
1594- MUXCBL	Cable, 2590 Multiplexer	
1594- MUXINPUT	Cable, 2590 Scanner Channel Input	
2383-1	Cable, Serial to USB Converter	
2571	Adapter, DWF to Spade Lugs, 1-Channel	
2572-1	Adapter, 5-pin (F) DIN to Spade Lugs	
2373	Adapter, INFO-CON to Spade Lug	
2373-DIN	Adapter, Rnd INFO-CON to Spade Lug	
	This adapter is designed for use with the 1594A/1595A Super-Thermometers.	
2373-LSP	Adapter, Female Lemo to Spade Lug	

5430-25	Resistor, AC/DC Standard w/ Cal, 25 ? 1-year stability, 2 ppm
5430-100	Resistor, AC/DC Standard w/ Cal, 100 ? 1-year stability, 2 ppm
742A-25	Resistor, DC Standard, 25 ? 1 year stability, 8 ppm
742A-100	Resistor, DC Standard, 100 ? 1 year stability, 6 ppm
1960	Cal, Standard AC/DC Resistor
2590	Multiplexer/Scanner, 10 Channel
Priority Gold Instrument CarePlan	Fluke Calibration Priority Gold Instrument CarePlans are available for most calibration products. Please contact your local Fluke Calibration sales representative for details or to request a quote. You may also call the Customer Care Center at 877-355-3225 or send email to careplans@flukecal.com .
Silver CarePlan	Fluke Calibration Silver CarePlans are available for most calibration products. Please contact your local Fluke Calibration sales representative for details or to request a quote. You may also call the Customer Care Center at 877-355-3225 or send email to careplans@flukecal.com .







©1995-2015 Fluke Corporation

 $\textbf{Source URL:} \ \underline{\textbf{http://us.flukecal.com/products/temperature-calibration/digital-thermometer-readouts/1594a1595a-super-thermometers}$