

## G. MAINTENANCE INTERVALS

### a. K008-3, U10-3 EU-version

No.	Checkpoints	Intervals	Hour meter indicator													Consequently					
			50	100	150	200	250	300	350	400	450	500	550	600	1000		2000				
1	Fuel	check	Daily check																		
2	Engine oil	check	Daily check																		
		change													○				○	○	every 500 hrs
3	Hydraulic oil**	check	Daily check																		
		change																	○		every 1000 hrs
4	Coolant	check	Daily check																		
		change																			every 2 years
5	Lubrication points	check	Daily check																		
6	Radiator	check	Daily check																		
7	Battery condition	check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 hrs
8	Electrical lines	check	Daily check, Annual servicing																		
9	Greasing of swing bearing teeth	—	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 hrs	
10	Fan belt tension	adjust				○				○						○	○	○	every 200 hrs		
11	Radiator hoses and clamps	check				○				○					○	○	○	every 200 hrs			
		change																	every 2 years		
12	Air filter element*	clean				○				○					○	○	○	every 200 hrs			
		change															○	○	every 1000 hrs		
13	Greasing of swing ball bearings					○				○					○	○	○	every 200 hrs			
14	Fuel pipes and hoses	check				○				○					○	○	○	every 200 hrs			
		change																	every 2 years		
15	Engine oil filter	change													○		○	○	every 500 hrs		
16	Fuel filter	check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 hrs		
		change														○		○	○	every 500 hrs	
17	Hydraulic return filter element	change															○	○	every 1000 hrs		
18	Hydraulic suction filter element	change															○	○	every 1000 hrs		
19	Front idler and track roller oil	change																○	every 2000 hrs		
20	Dynamo and starter motor	check																○	every 2000 hrs		
21	Radiator system	rinse																	every 2 years		

#### IMPORTANT:

- \* Clean the air filter more frequently if used in dusty conditions. With heavy soiling, replace the filter.
- \*\* When using a hydraulic breaker, change hydraulic oil and return filter according to the table on "Hydraulic Oil Change (Including Exchange of the Suction Filter in the Hydraulic Tank) under "EVERY 1000 SERVICE HOURS" in REGULAR CHECKS AND MAINTENANCE WORK".
- From 2007 Oct. production, Engine oil change interval will be prolonged from every 100 hrs to every 500 hrs, only on the conditions of using CF/CF-4 engine oils and / ultra-low sulfur fuel.