


In-Use Screen

After a Massage program is selected, In-use screen displays all settings to that program.



- 1 3D intensity level
- 2 Active airbags
- 3 Active rollers
- 4 Time left
- 5 Indicators
- 6 Back-roller position & direction
- 7 Bluetooth connected

Intelligent Voice Control

To activate the voice control feature on your remote: **Menu > Setting > Voice > On.**

Touch the button on the left speaker, or say "Switch to voice mode" to complete voice control activation.

Use the voice control commands below:
(Once you've activated voice control, give a command within 5 seconds, or you will have to re-activate the voice function.)

- Power On
- Switch Off
- Activate Massage
- Sports Refresh
- Extension
- Rest & Sleep
- Working Relief
- Neck & Shoulder
- Waist & Spine
- Airbag Massage
- Deep Shiatsu
- Healthy Breath
- Massage Extend
- Zero Gravity
- Start Heat
- Heat Off

Share a photo and tag us:

@Infinitymassagechairs

@infinity_chairs

@Infinitymassagechairs

Don't forget to use **#lovemyinfinitychair**

INFINITY®

72 Stard Road, Seabrook, NH 03874
603-910-5000
www.infinitymassagechairs.com
Version 2.0

INFINITY®

Quick Start Guide

Evolution 3D/4D Massage Chair

INFINITY®

Multi-Functional Screen

Use the directional buttons below to navigate these menu screens. Then press OK to select

On/Off – Powers up the remote or returns the chair to the exit position and powers down remote


Menu – Shortcut to the home page of all menu screens

OK – After navigating to the command desired on the display, push OK to select

Feet Adjust – Press and hold up arrow to bring foot rest up, press and hold down arrow to bring foot rest down

3D – Press to increase or decrease 3D intensity of back mechanism. In-use screen displays intensity dial

Feet Extend – Press and hold to extend the leg length adjustment



Back Adjustment – Back mechanism position adjustment; press and hold up to raise, press and hold down to lower. Use during initial body scan fine tuning or in manual point zone mode

Auto – Select from seven pre-set massage programs:

- Sports Refresh
- Extension
- Rest & Sleep
- Workign & Relief
- Neck & Shoulder
- Waist & Spine
- Demo

Directional Button – Press up, down, left or right to navigate the display screen

Seat Back Position – Press and hold down arrow to recline the seat back, press and hold the up arrow to upright the seat back

Feet Retract – Press and hold to retract the leg length adjustment