
Ensure the Footrest assembly swings freely up and down, Electrical connections are firmly attached and air hose




Zipper the closure between the Footrest and Chair Body



Double check that all airhose and electrical wires are still firmly connected in the back of the chair under the armrests. You can see the connections in the back of the chair, underneath the arms when fully upright.

Final Check:



on the back side of the it into the respective port electrical outlet and plug VOII behnunded 110V Connect the chair power :S qət2

further into the frame. the arm panels, push them pinching tmen while installing the chair body. To avoid

G

7

3

2

:c q9t2

:4 qət2

Step 3:

Locate air hoses on the side of

turn off main power switch.

reclined. Once fully reclined,

button until the chair is fully

nwob **taujbe Abed** adt blod

screen, and then press and

on. From the home screen,

fasten. Do not force.

Screw on metal ring to

remote port before inserting.

with the notch on the tablet

tablet remote cord lines up

Ensure the notch on the

the chair body and fasten.

located on the front right of


into the tablet remote port


Plug the tablet remote cord


main power switch to on.

base of the chair. Flip the

navigate to the adjustments







səsoH riA

Assembly Guide

MASSAGE CHAIRS

sleivotut-vldmesse\moo.sviedoegessemvtinitni.www Before assembling your chair, watch an assembly video at:


Alternatively, scan the QR code to go directly to the URL above.






contents to the detail below. Make sure all contents are accounted for. Prior to assembly, carefully unpack all box contents. Check box

603-910-5000. Do not return to the place of purchase. If anything is missing, please contact INFINITY at



secure. Remove the foot pads to increase foot roller intensity, if desired.



Review chair for smooth operation. If things are not operating correctly, review all assembly steps. Call Infinity support at 1-603-910-5000 if you need live US-based support

If you wish to use an APP to control the chair, download from the Apple or Google app store and follow pairing instruction found within the APP.

You are done; time for a Massage!



Power on the

remote and select

AUTO program to start a session.

> Register your product at www.infinitymassagechairs.com/ warranty to ensure it is in our system. This will simplify the warranty process should you ever need it.

Alternatively, scan the QR code to go directly to the URL above.

INFINITY[®] 72 Stard Road, Seabrook, NH 03874 | (603) 910-5000 | www.infinitymassagechairs.com

Version 1.1




Palisade[™] Pro 4D Massage Chair

INFINITY MASSAGE CHAIRS

Step 6: 6


Determine the left arm panel from the right and place next to the correct side of the chair. Note the locations of the arm panel clip, chair body rail, arm panel pin and the chair body hook.




Step 7:

7

To attach the arm panel to the chair body, place the arm panel clip over the chair body rail.








8

Ensure the arm panel clip remains on the chair body rail as you lift up the front of the arm panel slightly. Place your free hand on the back of the arm panel pushing it in towards the chair body, then push down on the front of the arm panel and slide the arm back so that the chair body hook aligns with the arm panel pin. Make sure that the hook and the pin are firmly in place before moving onto the next step.




To secure the arm panel to the chair body, Locate the screw holes by the foot well of the chair body and insert the short black screw and washer. Hand-tighten.




Step 11:

Locate the tablet holder from the accessory box. Place the tablet holder into the tablet holder mount, making sure to line up the bottom post of the tablet holder with the inside of the mount, screw down mount fastener to secure. Place the tablet remote into the tablet holder.





Step 13: To finish each arm, locate the air hoses you previously tucked into the chair body frame and connect to the air nozzles located on the back of the arm panel. Make sure to connect the corresponding hoses to their nozzles by matching the numbers. Repeat on other side.



Step 10:

Next, locate the screw

the Velcro cover and insert

the long silver screw and

washer. Tighten by hand, then finish the whole side with the hex key. Close


velcro back up.

holes underneath the shoulder airbags. Pull back

10

12

Step 12: Turn the main power switch on. Press the power button on the tablet remote. From the home screen, navigate to the adjustments screen, and then press and hold the **back adjust** up button until the chair is fully upright.




M8 x 40 (Long Bolt)

M8 x 24 (Washer)

Step 14:

14


Remove the footrest from its packaging and position it in front of the main chair body. Connect the footrest by attaching the three white plugs from the footrest into their respective ports on the body of the chair. Ensure the thumb release is facing up and push in until it clips. Slide the air hose onto the white air nozzle.



Note: look at the back side of the chair, under the arms to find these connections.



Step 15: Before attaching the footrest to the chair body, Remove the clips on the chair body pins by sliding up. (If Clips are missing, there are spare clips in the Accessory Box)





Lift the footrest and slide one side of the mounting bracket completely onto the chair body pin. Fasten the clip over the pin to secure. Carefully align the other side of the mounting bracket with the remaining pin and slide it on too. Make sure to center the footrest, then fasten the remaining clip over the pin to secure both sides of the footrest.

