


In-Use Screen

After a Massage program is selected, In-use screen displays all settings to that program.



Auto Programs

The chair features 3 built-in Auto Programs, while using the auto program the chair will switch automatically and activate combinations of massage functions.

Auto Program: RELAX / HEALTH CARE / WELLBEING
Press corresponding button to turn on/off the desired Auto Program. Once selected, the chair will automatically begin scanning your body, mapping your back, shoulders, and neck. During this process it is important to remain seated back into the chair without lifting your head. All auto message programs switch width and speed automatically.

ZONE

Press 'Zone up/down' buttons to toggle between massage zones: **Shoulder, Back, Waist, Point, Partial, Full**. Pressing UP button, moves through the options counter clockwise. Pressing DOWN button, moves through the options clockwise:

- Shoulder** massages the shoulders only.
- Back** massages the midback only.
- Waist** massages the lowerback only.
- Point** stops the massage mechanism in it's current position.
- Partial** travels a few inches above and below current position.
- Full** travels the entire length of the massage track.

Partial and Point location can be fine tuned using the massage zone adjust up/down buttons.

Note: 'point' massage zone can't be selected while in Shiatsu massage mode.

Massage Time

The preset massage time is 15 minutes. You can add time to your massage by using the **Timer button**. Each press adds 5 mins to the massage time. The LCD screen will show countdown.

Manual Controls

Press the manual control button to toggle between ALL massage modes. Modes will occur in the following order: *Reverse Kneading* → *Kneading* → *Shiatsu* → *Tapping* → *Duplex* → *Reverse Duplex*. The selected massage function pattern will be displayed on the screen.

In addition to different massage modes, you also have the ability to tailor your massage to your exact needs. Use the **Intensity adjustment button** to control the intensity of your massage. Adjust the speed of your massage by using the **Speed adjustment button**. Control the width of the back massage rollers by using the **Width adjustment button**. Add air massage to your massage experience by using the All air button or select individual air massage zones by using the **Calf/Seat air massage** button.

Share a photo and tag us:

- @infinity_chairs
- @Infinitymassagechairs
- @Infinitymassagechairs

Don't forget to use
#infinitymassagechairs

INFINITY
72 Stard Road, Seabrook, NH 03874
603-910-5000
www.infinitymassagechairs.com
Version 1.0

INFINITY
MESSAGE CHAIRS

Quick Start
Guide

IT-9810
Massage Chair



Alternatively, **scan the QR code** to watch a remote tutorial video.

INFINITY®

Display Screen

Power (Start / Stop)
Press this button to turn on/off the chair.

Timer
Press button to set timer from 5 to 30 minutes. Each press will add 5 mins.

ZONE
Press up/down button to toggle between Full, Partial, Point, Waist, Back, Shoulder.

Width Adjustment
Width Adjustment for Tapping and Shiatsu Manual programs. Choose between wide, medium or narrow.


Manual Controls
Press the manual control button to toggle between ALL massage modes.

Rocking Function
Press button to turn on/off the rocking function.

Calf/Seat Air Massage
Press the Calf or Seat button to start air massage in that respective area. Press specific area again to turn air off.

Speed Adjustment
Press up/down to adjust massage speed. Choose between 6 speed settings.

Zero Gravity Reclining Adjustment
Press to recline into weightless zero gravity recline position.



- Pause**
Press to pause massage. All massage functions will stop. Press again to resume massage.
- AUTO Programs**
Press any of the 3 AUTO program buttons to select pre-programmed choreographed massages: *Relax, Healthcare, or Wellbeing*.
- Back Roller Adjustment**
Long press the up or down button to adjust the position of the back mechanism while in point or partial massage zone.
- All Air Massage**
Press button to turn on/off ALL airbags. Selecting this option will override any other airbag selections you have made previously.
- Intensity Adjustment**
Press the up or down button to adjust the intensity of the massage. Choose between 6 intensity levels.
- Kneading/Duplex Reverse**
Press for 2 additional manual massage modes: reverse kneading or reverse duplex. Both buttons will play the respective mode in reverse.
- Manual Massage Mode**
Select between 4 different manual massage modes: Kneading, Shiatsu, Duplex, or Tapping.
- Backrest Adjustment (Up / Down)**
Long press up/down to upright or recline the chair backrest.
- Recline**
Press to recline into standard reclined position.