

In-Use Screen

After a Massage program is selected, the In-Use screen displays all settings to that program.



- 1

Status Icons
- 2

Position & Direction
- 3

Settings
- 4


Running Program
- 5

Play/Pause/Home
- 6

Sleep Mode
- 7

More Options

Voice Commands List



The Voice Commands listing can be found under System from the Home menu. Control your chair and massage experience completely hands-free by using one of the many voice commands. To activate, say the phrase “Hey Kyota” or “Hi Kyota.”

Kyota is pronounced:
“Key-Oh-Ta”

Quick Access Panel + Dial & Button Control

The Quick Access Panel + Dial & Button Control allows you to turn the chair on and off and control chair angles.




Dial & Button Control:

- Turn dial right or left to increase/decrease the recline mechanism
- Press & hold power button turns message chair on/off.
- Tap of power button cycles through ALL auto programs. Name of program is shown on tablet.

- Smart Massage** - Tap to run Smart Massage
Rocking - Tap to run Rocking Feature
Heat - Tap to turn on/off Heat
Foot Roller - Tap to turn on/off Foot Rollers
Airbags - Tap to turn on/off Airbags
ZeroG - Tap to turn/off Zero Gravity
Waist Cooling - Tap to turn on/off Cooling
Sleep Mode - Tap to turn on/off Sleep Mode

KYOTA®


Quick Start Guide




Alternatively, scan the QR code to watch a remote tutorial video.

Kizuna M688
Massage Chair


KYOTA®




Auto Programs – Select from 12 pre-set auto programs. To select, simply tap the auto program you wish to run. To return to previous screen, tap the top left arrow.




Favorite – While running the program you wish to save, tap Favorite. Then tap Save in the slot you would like it stored. Return anytime to the Favorite screen and tap the corresponding Run button to recall and start the saved program.




Adjustments – Tap adjustments to change your chair’s recline setting, turn on/off Meditation Music, Zero Gravity, Rocking, and add or reduce time.



Home Page – After turning on your chair, this is the first screen you will see. Use this screen to navigate all menu options. While running a program, tap the Home icon to return here.




Sound – Choose from 10 pre-set nature sounds. Tap to select the sound then set your volume level. To turn the sound off, de-select the activated sound.



Manual Settings – Use this screen to fully customize your own massage and find the perfect treatment for you. Manual Programs can also be saved as a Favorite after the program starts running, for easy recall.



Smart Massage – Tap Smart Massage and place your Index finger on the health sensor in the front of the Right armrest. The AI algorithm will combine your health scan with massage techniques to recommend a program specifically for you. When scanning is complete, view your scanned readings and tap to run the program.



Settings – Displays Sleep Mode, Bluetooth, Voice Control, and more.