

Airbag Intensity


When in-use screen is showing:



Use directional buttons - **Right** side to increase intensity - **Left** side to decrease intensity

When main menu is showing:

Navigate to **AIRBAG** and press **OK**. Navigate to **FORCE** select **OK**. Set intensity desired by selecting 1 (lowest) through 5 (highest) and pressing **OK**.



Note: Airbags must be active to set intensity level

Share a photo and tag us:

@Infinitymassagechairs



@Infinitymassagechairs

Don't forget to use **#lovemyinfinitychair**

INFINITY° 72 Stard Road, Seabrook, NH 03874 603-910-5000

www.infinitymassagechairs.com Version 1.4

INFINITY®

Quick Start Guide



Smart Chair X3 4D Massage Chair

